

GETINGE

GETINGE 88-SERIES
TECHNICAL MANUAL
502406700



SEV0839001-

GETINGE

Contents

FOREWORD	6
SAFETY REGULATIONS	7
Important	7
In an emergency	7
Product liability	7
Isolating device	7
INTRODUCTION	8
Intended use of the machine	8
Attention symbols	8
Residual current device (RCD)	8
Description	9
General	9
Control system	9
Aborting program start	10
Aborting a running program	10
Schematic diagram	11
Electric heating	11
Explanation of symbols	11
Steam heating	12
Explanation of symbols	12
Software description and settings	13
Description	13
Control panel	14
Display	14
Program selection buttons	14
Menu selection buttons	15
Scrolling in menus and lists	16
Field editing	16
Passwords	17
Menu tree	19
Menu tree	20
P-parameters	56
PREVENTIVE MAINTENANCE	58
General	58
Periodic maintenance	58

Function check	59
Instruction manual, cable, switch	59
Filters and valves	59
Strainer	59
Controls	59
Insert for goods	59
Door	60
Detergent dosing	60
Washing system	60
Temperature check	60
Dryer	60
Hoses	60
Printer	60
Cooling fans in electrical cabinets	60
Power cables	60
Fault indications	61
Handling alarms	61
Alarm	62
Troubleshooting	63
Repair and adjustment	70
Connecting a PC	70
Connections	71
Fixed scanner	71
Printers	72
NetCom	75
Connection AGS	76
Connection loader/unloader	77
Termination central dosing	79
Potential free contacts	80
Loading programs to flash memory	81
Loading system programs	81
Load language files	84
Loading a new application into PACS	85
Reloading the backup from “flash prom” to PACS	86
Cold start	87
Changing user language	88
Calibration	89
Pressure sensor for circulation pump	92
Temperature sensors - with resistor	94
Temperature sensor - with ice bath and oil bath	96
Differential pressure gauge for dryer	98
Calibration of drying sensor	101

GETINGE

Dosing pumps and flow transmitters	103
Calibration of flow transmitters	103
Trim panels	105
Clean side and soiled side	105
Side panels	105
Replacing a temperature sensor	106
In wash chamber and dryer	106
In a booster tank	106
Door	107
Position and operation, door switches	107
Adjusting door switches	108
Adjusting DOOR UP safety switch	109
Replacing the door seal	110
Removing the door	111
Adjusting the door closing force	112
Adjusting the door frame	112
Overheat protection	113
Cleaning the water and steam valve	114
Dryer	115
Changing the filter	115
Fan replacement and checking	115
Check valves to main pipe	115
Conductivity measurement (extra equipment)	116
Function in washing process	116
Measuring range	116
Replacing the main board	117
Replacing the expansion board	118
Replacing fuses	119
Replacing a hose to a hose pump	121
Setting detergent and rinse-aid quantities	122
Servicing the booster tank	123
Booster tank with drain tap	123
Overheat protection	123
Process valve and diaphragm	124
Checking	124
Adjusting (adjustment allowances)	124
Repair	124
Replacing the diaphragm	124
Booster pump	125

Process tank	126
Draining the process tank	126
Replacing a sensor	126
Cleaning	126
Disinfecting the process tank	126
Volume calibration	126
Drain valve	129
Checking	129
Adjusting (adjustment allowances)	129
Repair	129
Replacing the diaphragm	129
Waste tank	130
Replacing and adjusting sensors	130
Manual cleaning	130
Waste pump	131
Checking	131
Replacement	131
Water valves	132
Replacing a filter	132
Replacing the valve	132
Steam valves and condensation traps	133
Replacing and cleaning filters	133
Replacing a steam hose	133
Detergent cabinet	134
Dosing pump and flow transmitter	135
Replacing a dosing pump	135
Replacing a flow transmitter	135
Replacing a pressure sensor	136
Replacing the differential pressure sensor	137
Frequency converter	138
Replacement	138
Configuration	139
MONITORING SYSTEM	145
Description	145
Software description and settings	146
Field editing	147
Passwords	148
P-parameters	149
Loading programs to flash memory	151
Loading system programs	151

GETINGE

FOREWORD

This service manual is intended for maintenance and service personnel working with Getinge 88-series washer disinfectors.

The service manual is divided into the following sections:

- Safety regulations
- Introduction to the machine
- Software description and menu tree
- Preventive maintenance
- Fault indications and troubleshooting
- Repair and adjustments
- Electrical diagram of the washer disinfectors
- Monitoring system (Option)
- Electrical diagram of the monitoring system

The purpose of the service manual is to provide information for the maintenance and service personnel whose job it is to ensure safe operation with optimum efficiency. See under Intended use on page 8.

Before starting work on the machine, the maintenance and service personnel must have read the safety instructions in this manual and familiarized themselves with the operation of the machine and its safety instructions. They must also have done a service training course at Getinge Academy



Read the safety instructions in the service manual before starting work on the machine.

The information in this manual describes the machine as dispatched from Getinge. There may be differences due to customization.

The machine is accompanied by the following documentation:

- User manual
- Installation manual
- Technical manual (this book)
- Spare parts list
- Goods positioning instructions

The goods positioning instructions supplied must be put up in a clearly visible position at the time of installation.

Getinge reserves the right to change the specification and design without prior notice.

The information in this manual was up to date on the date of issue of the manual.

© Copyright

The content of this manual must not be copied, in whole or in part, without the written consent of Getinge.

SAFETY REGULATIONS

This machine has been designed with a number of built-in safety devices. To avoid injury, it is highly important not to bypass or disable these safety devices. If the equipment is used in a manner not specified by the manufacturer this can impair the safety equipment on the machine.

NOTE:

Before starting any servicing or maintenance work on the machine, isolate it from the incoming electrical supply, shut off water and steam supplies and drain the process, booster and waste tanks.

Important

- Take care when handling the chemical agent used in the machine. Read the details on the container or contact the manufacturer:
 - if the agent comes into contact with the operator's eyes or skin or if the vapors are breathed in, etc.
 - about storing the agent and disposing of empty containers.
- The machine must be connected in accordance with the installation instructions. (Check against the rating plate)
- The machine may only be operated by adults.
- Installation and service work must be done by personnel trained in the use of this machine.
- Never bypass the door switch of the machine.
- Leakage in the system, due to a worn door seal for example, must be repaired without delay.
- Before repair or service work is done, the personnel concerned must study the relevant handbooks and service manuals.
- Before welding begins on or close to the machine, all wiring connected by plugs and sockets must be disconnected from all circuit boards in the machine.
- The machine must not be hosed down with water.
- Take care when using corrosive detergents.
- Precautions must be taken with hot water and steam.
- Run a program with disinfection before starting servicing work. If this is not possible, disinfect the machine with disinfectant before starting servicing work.
- Before starting servicing work on the machine, make sure that the tanks (booster tank, process tank, chamber and waste tank) do not contain any water.
- Before starting any servicing or maintenance work on the machine, isolate it from the incoming electrical supply, shut off water and steam supplies and drain the process, booster and waste tanks.
- Spare parts may only be obtained from Getinge EDC.

In an emergency

- Switch off the main switch
- Close stopcocks in the water and (where present) steam supply lines.

Product liability

Any modification or incorrect use of the equipment without the approval of Getinge Disinfection AB invalidates Getinge Disinfection AB's product liability.

This product was manufactured by:

GETINGE DISINFECTION AB
Ljungadalsgatan 11, Box 1505
351 15 Växjö, Sweden



Isolating device

The machine must be fitted with a separate, lockable isolating device in the electric power supply. The isolating device must be easily accessible on a wall close to the machine. The installation must conform to and be marked in accordance with local provisions.

GETINGE

INTRODUCTION

Intended use of the machine

Getinge S-88 series machines are washer disinfectors intended for cleaning, disinfection and drying. Intended fields of application are surgical instruments (solid and tubular), dishes, hand bowls, glass goods, suction flasks, baby bottles, anaesthesia equipment and OP shoes. Depending on program design.

Validation of goods according to intended use is done with Getinge Disinfection AB's standard loads.

An Installation Qualification, an Operating Qualification and a Performance Qualification according to ISO 15883 must be carried out before putting the machine into service.

Incorrect use can result in damage to objects and personal injuries

Attention symbols

Some of the warnings, instructions and advice in this manual are so important that we use the following special symbols to draw attention to them. The symbols used are as follows:



This symbol indicates a warning in the service manual. It warns of a hazard that may lead to more or less severe injury and in certain cases mortal danger.



It also highlights warnings to avoid damage to equipment. This symbol highlights a warning in the text of the service manual dealing with the handling of components sensitive to ESD. The hazard that it warns about may result in damage to hardware and/or circuit boards.



This symbol highlights the risk of injury by burning. The part or the surface may be very hot.



This symbol shows that voltage is or may be present in the machine or parts of the machine.

Residual current device (RCD)

If it is intended to use a residual-current device (RCD)(30 mA personal protection) with the machine, the RCD must be of class 4P B.


Description

General

A description of the mechanical design and general functions of the machine is given in the instruction manual. This section contains a general description of the control system. For detailed information about the software and its settings, see the chapter entitled Software description and settings.

Control system


The machine has an electronically programmable control system which can hold 12 programs. The control system is operated from the control panels of the machine, to the left of the door on the soiled side.



Six of these programs can be started with the program selection buttons. With **P1** - **P6** you can choose up to six programs. If the control system has more programs, the subsequent ones are chosen from a scrollable list. You can reach the list of available programs (from standby mode), by pressing twice and choosing a program with or . Confirm the chosen program with .

The machine comes with a number of standard programs in the programmer (see the appendix for Standard programs). Parameters in these programs can be modified to suit the needs of individual users. Individual programs can be created with a PC. An entire standard program or parts of one can be used as a starting point for programming. Programming may only be done by an authorized service technician.

GETINGE






*The times may vary because of different media.



P02

Program cycles

①	Pre-rinse 1	A	Alkaline detergent
②	Pre-rinse 2	B	Neutralization
③	Wash	C	Instrument milk (<i>extra equipment</i>)
④	Neutralization		If instrument milk is dosed, neutralization is not dosed.
⑤	Post-rinse 1	D	Chemical disinfection
⑥	Post-rinse 2		
⑦	Final rinse		
⑧	Disinfection		
⑨	Drying		

Programs are chosen with the program selection buttons and the program is started with  (starting of a program is indicated by the yellow lamp at  flashing for 5 seconds and then going out). When the program is complete, a green lamp lights up at  and the clean-side door opens automatically. (The door can stay closed after completion of the process by a setting in the program. In this case the door is opened via the OP panel on the clean side). The illustration at the top of the page shows the program sequence in the OP-D program.


Aborting program start

A started program can be aborted within 5 seconds of the machine starting to close the door on the soiled side. To abort a started program, press  again. During the period when the program can be aborted, a yellow lamp flashes at . The door is unlocked and opened automatically and the machine can be restarted in the usual way.

Aborting a running program

While a program is running, the machine can be stopped with the main switch. This cuts off the power supply and fault code F00 POWER FAIL is displayed. The alarm is acknowledged by normal acknowledgement (see the user manual).

Schematic diagram Electric heating



Explanation of symbols

Connection lines etc.

	Main flow line
	Subsidiary flow line
	Optionel equipment
	Optionel equipment
	Dimension of piping
	Connections
	No connections
	Limits of supply with identification code
	Flow direction
	Spray Nozzle

Heat exchangers

	Heat exchanger air/air
--	------------------------

Valves

	Valve manually activated
	Valve solenoid activated
	Valve pneumatic activated

Motor Objects

	Pump
	Blower/Fan
	Electric heater
	Electric motor

Filters

	Filter air
	Filter liquid

Motor Objects

	Pump
	Blower/Fan
	Electric heater
	Electric motor

Auxiliary

	Check valve
	Steam trap
	Drain
	Hose


Instrument functions

	Control system connected instr.
	Local control (Hardware)
	Local
	Instrument function tag number

V1560

GETINGE

Steam heating



Explanation of symbols

Connection lines etc.

	Main flow line
	Subsidiary flow line
	Optional equipment
	Optional equipment
	Dimension of piping
	Connections
	No connections
	Limits of supply with identification code
	Flow direction
	Spray Nozzle

Heat exchangers

	Heat exchanger air/air
--	------------------------

Valves

	Valve manually activated
	Valve solenoid activated
	Valve pneumatic activated

Motor Objects

	Pump
	Blower/Fan
	Electric heater
	Electric motor

Filters

	Filter air
	Filter liquid

Motor Objects

	Pump
	Blower/Fan
	Electric heater
	Electric motor

Auxiliary

	Check valve
	Steam trap
	Drain
	Hose

Instrument functions

	Control system connected instr.
	Local control (Hardware)
	Local
	Instrument function Tag number

V1560

Software description and settings

Description

This section describes the PACS 350 control and monitoring system. The purpose of the control system is to monitor safety and gather information and send it to the executive components of the washer-disinfector so that a number of disinfection processes can be performed in accordance with a predetermined template. The order signals are worked out by the computer program of the control unit in conjunction with measurements of actual parameter values for the current program. These are usually times, temperatures and pressures.

Process selection

Several different pieces of equipment can be connected to the control unit for programming, monitoring and documenting the disinfection processes.

The operator communicates with the control unit via a control panel or an ordinary PC. All operator panels can be used to monitor the processes, since they display all the set parameter values as well as actual values on request.

Programs, system definitions and process data can be documented by connecting a printer to the unit. A host computer can also be connected directly to the CPU of the control system.


When the need arises, a measuring and monitoring system entirely independent of the control system can be set up by connecting a PACS MONITORING SYSTEM, consisting of CPU, operator panel and connections to the control unit CPU.

The computer contains programs for calibration of the temperature and pressure sensors. Where alternative correction constants are known, they can be entered manually. The testing functions include means of activating analog and digital outputs and for reading analog and digital inputs.

GETINGE

Control panel

The buttons on the control panel are used to choose programs, navigate the menu tree, acknowledge fault codes, etc.



Display

The display has two lines, each with a capacity of 20 characters.













Information or error messages appear on the bottom line and replace the text that would otherwise appear here.

Program selection buttons

With **P1** - **P6** you can choose up to six programs. If the control system has more programs, the subsequent ones are chosen from a scrollable list. You can reach the list of available programs (from standby mode), by pressing twice and choosing a program with or . Confirm the chosen program with .

Menu selection buttons

There are five buttons for navigating the panel. These fixed buttons are four arrow buttons that control the cursor (, ,  and ) and .

- •  Used to go back one step (up one level) in menus.
If the button is held down for a little longer, you are returned to the main menu. It also moves the cursor.
- •  Moves the cursor. Not used in menus and lists.
- •  Shows the next object in the list.
- •  Shows the previous object in the list.
- •  Goes to the chosen object in the list or opens a field for editing if there is an editable field.



GETINGE

Scrolling in menus and lists

You can use , ,  and  to scroll through menus and lists.


You can scroll either line by line or two lines at a time, depending on what is displayed. The top line of the list may look like the example below.

```
>PRINT LAST PRG.  
SYSTEM
```

The angle bracket “>” to the left of the top line shows which object will be chosen if you press . Bottom right there is a “v” indicating that there are more objects in the list which are displayed if you press .







This is what you see if you are in a list. The “arrows” to the right show that there are objects both above and below the displayed line.

```
>SYSTEM  
APPLIANCE INFO
```

When you reach the end of the object list, only one up-arrow appears at the right edge of the display. Menus and lists are “endless”; you can reach the top of the list by pressing  at the end of the list.

```
SYSTEM  
>APPLIANCE INFO
```

Field editing

 opens the chosen field for editing. The content of the field is changed with  or . These arrow keys scroll in an endless list containing numbers. When a field is opened for editing, the first character is highlighted. To move the cursor use  or . Entered values are saved when you press . On saving, the system checks that the value is in the permitted range.








Passwords

There are four passwords with different levels of authorization in the system program. The operator password has the lowest authority; the programming password has full authority.

The following password levels are as follows:

- Operator - code 558387.
- Supervisor - contact service for code.
- Service - contact service for code.
- Programming - contact service for code.

Note: In the menu tree, where a password must be entered, there is a letter code (between PW: A-K) which indicates which function the respective password level gives authorization for.

When a password is being entered, the top line shows “ENTER PASSWORD”. Press  to open the entry field for editing. Each digit can be changed with  and .  and  toggle between the digits. Press  to confirm the entered password. If the wrong password is entered, “WRONG PASSWORD” appears on the first line. Press  to return to the display that shows “ENTER PASSWORD”

Note: The password cannot be changed.

Operator

Code in menu tree	Authority to change
A	Parameters of type A and to see parameters of type I.
D	Acknowledge alarms

Supervisor

Code in menu tree	Authority to change
A	Parameters
B	Calendar (time and date)
C	Sensor calibration
D	Acknowledge alarms
H	Process-critical configurations, parameters of type P.
J	Password configuration
K	Documentation

GETINGE

Service

Code in menu tree	Authority to change
A	Parameters.
B	Calendar (time and date)
C	Sensor calibration
D	Acknowledge alarms
E	Service messages
F	DIP switches
G	Non-process-critical system configurations
H	Process-critical configurations, parameters of type P.
J	Password configuration
K	Documentation

Programming


Code in menu tree	Authority to change
A	Parameters.
B	Calendar (time and date)
C	Sensor calibration
D	Acknowledge alarms
E	Service messages
F	DIP switches
G	Non-process-critical system configurations
H	Process-critical configurations, parameters of type P.
I	Programming (phases and programs)
J	Password configuration
K	Documentation

Menu tree


Menu tree	20
Main menu 1, Program name (1.1)	22
Choose a program	22
Change parameters (1.1.2)	23
Main menu 2, Machine name (1.2)	23
Machine information (1.2)	23
Main menu 3, Cycle counter (1.3)	24
Variable list (1.3.1...)	24
Main menu 4, Settings (1.4)	25
Print parameters of the chosen cycle (1.4.1)	25
System menu (1.4.2)	25
Calendar menu (1.4.2.1)	25
Time menu (1.4.2.1.1)	26
Date menu (1.4.2.1.2)	26
Calibration menu (1.4.2.2)	27
Manual calibration menu (1.4.2.2.1)	27
Automatic calibration menu (1.4.2.2.2)	28
Calibrate the chosen sensor (1.4.2.2.2.1)	28
Choose a sensor (1.4.2.2.2.2)	29
Compensation table menu (1.4.2.2.3)	30
Configuration menu (1.4.2.3)	30
Language menu (1.4.2.3.1)	30
Date format menu (1.4.2.3.2)	31
Unit of pressure menu (1.4.2.3.1.3)	32
Temperature unit menu (1.4.2.3.1.4)	33
Printer menu (1.4.2.3.2)	34
Print mode menu (1.4.2.3.2.1)	34
Slow interval menu (1.4.2.3.2.2)	35
Fast interval menu (1.4.2.3.2.3)	36
Transfer speed menu (1.4.2.3.2.4)	37
Alarm clock menu (1.4.2.3.3)	37
PACS address menu (1.4.2.3.4)	38
Communication settings COM0 (1.4.2.3.5.1)	39
Communication settings COM1 (1.4.2.3.5.2)	40
Communication mode COM2 (1.4.2.3.5.3)	41
Change cycles (1.4.2.3.6.1)	42
DIP switch menu (1.4.2.4)	43
Service menu (1.4.2.5)	44
Fault log menu (1.4.2.5.1)	44
Service message menu (1.4.2.5)	45
Diagnostics menu (1.4.2.5.3)	45
Test analog in menu (1.4.2.5.3.1)	46
Test analog out menu (1.4.2.5.3.2)	47
Test digital in menu (1.4.2.5.3.3)	48
Test digital out menu (1.4.2.5.3.4)	49
Test user flag menu (1.4.2.5.3.5)	50
Test printer (1.4.2.5.3.7)	51
Test LED/buzzer display (1.4.2.5.3.8)	52
Save RAM in flash menu (1.4.2.6)	53
Appliance info (1.4.3)	53

GETINGE


Menu tree




- * Operator password required
- ** Service personnel password required




1.4.2.2 CALIBRATION



1.4.2.3 CONFIGURATION



1.4.2.5.3 DIAGNOSTICS



GETINGE

Main menu 1, Program name (1.1)





In standby mode the top line of the display shows the name of the last cycle chosen. The second row shows two preselected values, normally this is the temperature in the machine and the cycle counter. The main purpose of this menu is to choose a wash cycle and to be able to change parameters.


This menu has two submenus.

SELECT PROGRAM (1.1.1)

CHANGE PARAMETERS (1.1.2)

Select the program.

In the main menu 1 press  to move to the SELECT PROGRAM menu then press enter again to reach the various programs. Use the  and  buttons to highlight the program you want to use. To select a program press . The cycles are pre-configured in the program and cannot be changed by the operator.



Change parameters (1.1.2)


In main menu 1, press to go to the SELECT PROGRAM menu. Then press to activate "CHANGE PARAMETERS". To select a program, press again.

Every cycle has a set of preset parameters. When a cycle has been chosen as explained in the previous section, the parameters appear on the display. The number of the parameter depends on how the cycle was configured when it was created in the program.

The parameters that have an "A" indication in the bottom right corner are adjustable. With a class A password, the value can be changed by pressing .

If an "I" is displayed in the same position then the parameters are only information.

P parameters can only be changed with class A + H passwords.




Main menu 2, Machine name (1.2)

Main menu 2 shows information about the machine and the current phase. The information cannot be changed.

Machine information (1.2)

The top line shows name/ID of the disinfection program and the bottom line shows the current phase.







GETINGE

Main menu 3, Cycle counter (1.3)

In this menu, a selectable variable can be displayed. The top line shows the name of the variable and the bottom line shows the value of the variable.

Variable list (1.3.1...)

There is a configured number of variables for every cycle. This list is only for information about the variables. To choose the variable you want to see, press  or , then press  to display the chosen variable.



Main menu 4, Settings (1.4)

Main menu 4 is the settings menu for the machine. The settings menu has three submenus.






Print the parameters of the chosen cycle (1.4.1)


System setting menus. (1.4.2)

Appliance information. (1.4.3)

Print parameters of the chosen cycle (1.4.1)

When a cycle has been chosen in main menu 1, the parameters of that cycle can be printed out.

Press  three times to reach the settings menu, then press  to choose settings. Pressing  once more brings up the printing screen. Use  or  to choose "YES" to start printing or "NO" if you do not want to print the chosen cycle.



System menu (1.4.2)

The system settings menu has six submenus.

A calendar where you can enter the date and time. (1.4.2.1)

Calibration of analog entry values. (1.4.2.2)

Configuration of devices such as printer, alarms, alarm clocks and node addresses. (1.4.2.3)

DIP switches. (1.4.2.4)

Service menu with fault message, service message and diagnostics. (1.4.2.5)

Save RAM in flash. (1.4.2.6)

Calendar menu (1.4.2.1)








The time and date can be set in this menu. There is a submenu for each function.


Set time. (1.4.2.1.1)

Set date. (1.4.2.1.2)

GETINGE








Time menu (1.4.2.1.1)


To set the time, follow the instructions in the menu tree below. Enter password and press  when the calendar menu has been chosen. To set the time, press . To change the time press  and  until the desired time is displayed. Then use  or  to change field. When the value is correctly set, press  to confirm the change.



* Service personnel password required

Date menu (1.4.2.1.2)

To set the date, follow the instructions in the menu tree below. Enter password and press  when the calendar menu has been chosen. To set the date, press . To change the time press  and  until the desired date is displayed. Then use  or  to change field. When the value is correctly set, press  to confirm the change.



* Service personnel password required

Calibration menu (1.4.2.2)

The calibration menu is used to calibrate analog entry values. There are three submenus for calibration.


Manual calibration. (1.4.2.2.1)

Automatic calibration. (1.4.2.2.2)


Adjusting the compensation table. (1.4.2.2.3)


Manual calibration menu (1.4.2.2.1)


In manual calibration, two values for A-Gain and B-offset can be entered manually. To access manual calibration, follow the instructions in the menu tree below. To change values, press and . Then use or to change field. When the value is correctly set, press to confirm the change.



Choose a sensor (1.4.2.2.2)

Press  when Choose sensor is highlighted under automatic calibration.

Confirm the choice by placing the cursor on "YES" and pressing  again. The sensor has now been chosen. Note that more than one sensor can be chosen at the same time. If more than one sensor is chosen at the same time, they must be of a similar type.



GETINGE

Compensation table menu (1.4.2.2.3)



This menu is not applicable on this machine.


Configuration menu (1.4.2.3)

The configuration display is used to set language, and units. The printer is also set here. The alarm clock and PACS addresses are also set here. There are four submenus.



- Language. (1.4.2.3.1)
- Date format. (1.4.2.3.2)
- Unit of pressure. (1.4.2.3.3)
- Unit of temperature (1.4.2.3.4)

Language menu (1.4.2.3.1)

Language settings for the various displays can be accessed in this menu. Press  and choose the required language. To confirm, press .




Date format menu (1.4.2.3.2)

The date format is chosen from this menu. There are three date formats: Press  to see the different formats. Then choose the date format you want. To confirm, press .

YYYY/MM/DD (1.4.2.3.2.1)



MM/DD/YYYY (1.4.2.3.2.2)

DD/MM/YYYY. (1.4.2.3.2.3)



GETINGE


Unit of pressure menu (1.4.2.3.1.3)

Three units of pressure are available: Press  to access the menu with the various units, then choose the unit you want. To confirm, press . Note: This only shows the available units. The value of these units is not converted.

BAR (1.4.2.3.1.3.1)

KPA (1.4.2.3.1.3.2)

PSI (1.4.2.3.1.3.3)




Unit of temp menu (1.4.2.3.1.4)

There is a choice of two units of temperature. Press to see the two units. Choose the unit you want to use and press to confirm.

Note: This only shows the available units. The value of these units is not converted.

Celsius. (1.4.2.3.1.4.1)

Fahrenheit. (1.4.2.3.1.4.2)



GETINGE


Printer menu (1.4.2.3.2)

All settings for printer and logs are made in this section. There are four submenus:


- Printer mode. (1.4.2.3.2.1)
- Slow interval (1.4.2.3.2.2)
- Fast interval (1.4.2.3.2.3)
- Printer transfer speed. (1.4.2.3.2.4)

Print mode menu (1.4.2.3.2.1)

This menu has only one option. Only process values are printed out.




* Service personnel password required



Slow interval menu(1.4.2.3.2.2)


The speed of the slow interval log times is shown here. The phases that use this time speed are pre-configured in the program for each phase.



GETINGE

Fast interval menu(1.4.2.3.2.3)


The speed of the fast interval log times is shown here. The phases that use this time speed are pre-configured in the program for each phase.



Transfer speed menu (1.4.2.3.2.4)

You can choose the transfer speed for the printer in this menu. There are four transfer speeds:

- 1200.(1.4.2.3.2.4.1)
- 2400.(1.4.2.3.2.4.2)
- 4800.(1.4.2.3.2.4.3)
- 9600.(1.4.2.3.2.4.4)



* Service personnel password required


Alarm clock menu (1.4.2.3.3)

This function is not used on this machine.

GETINGE


PACS address menu (1.4.2.3.4)

The node address for PACS is entered in this menu.



Communication settings COM0 (1.4.2.3.5.1)

Protocol type and communication mode are entered in this menu.



* Service personnel password required


Table

Com 1 protocol	For PC connection and T-Doc
Printer	For printer connection
Scanner 1	Handheld scanner connected
Scanner 2	Fixed scanner connected

GETINGE

Communication settings COM1 (1.4.2.3.5.2)

Protocol type is entered in this menu.




Table

Com 1 protocol	For PC connection and T-Doc
Printer	For printer connection
Scanner 1	Handheld scanner connected
Scanner 2	Fixed scanner connected

Communication mode COM2 (1.4.2.3.5.3)

Protocol type is entered in this menu.




Table

RS232	PC connected
RS485	T-Doc connected

GETINGE


Change cycles (1.4.2.3.6.1)

Protocol type is entered in this menu.




DIP switch menu (1.4.2.4)

The DIP switches are used to switch various options on and off. The various options are pre-configured in the program. There are 16 DIP switches in all. See Section 2.3.1



* Service personnel password required



Table

DS00	Machine with only one door.	DS08	Flow metering #4	DS16	XXXXXXXXXX	DS24	XXXXXXXXXX
DS01	Opens the door when the cycle is complete.	DS09	Conductivity measurement	DS17	XXXXXXXXXX	DS25	XXXXXXXXXX
DS02	Distilled water	DS10	AGS loader, soiled side	DS18	XXXXXXXXXX	DS26	XXXXXXXXXX
DS03	Dosing pump #3	DS11	AGS unloader, clean side	DS19	XXXXXXXXXX	DS27	XXXXXXXXXX
DS04	Dosing pump #4	DS12	Monitoring system	DS20	XXXXXXXXXX	DS28	Service messages
DS05	Flow metering #1	DS13	Scanner	DS21	XXXXXXXXXX	DS29	A ₀ -Value
DS06	Flow metering #2	DS14	XXXXXXXXXX	DS22	XXXXXXXXXX	DS30	PC washing log
DS07	Flow metering #3	DS15	XXXXXXXXXX	DS23	XXXXXXXXXX	DS31	Loop running

GETINGE

Service menu (1.4.2.5)

The service menu shows the various fault messages, service messages and diagnostics.


Fault log. (1.4.2.5.1)

Service messages. (1.4.2.5.2)

Diagnostics. (1.4.2.5.3)


Fault log menu (1.4.2.5.1)

The last 20 fault messages are displayed. The faults are confirmed with the Enter button on the PACS. You can find the fault messages in Section 3.



Service message menu (1.4.2.5)

Service messages attract the operator's attention if something needs to be done. You can find service messages in Section 3.



Diagnostics menu (1.4.2.5.3)


The diagnostics menu is used to test input and output data and flags. There are eight submenus:

- Test analog in. (1.4.2.5.3.1)
- Test analog out. (1.4.2.5.3.2)
- Test digital in. (1.4.2.5.3.3)
- Test digital out. (1.4.2.5.3.4)
- Test user flag (1.4.2.5.3.5)
- Test system flag (1.4.2.5.3.6)
- Test printer. (1.4.2.5.3.7)
- Test LED and buzzer. (1.4.2.5.3.8)

GETINGE


Test analog in menu (1.4.2.5.3.1)

These values are read-only. The status of various input data is displayed. The various input data are pre-configured in the program. To see the various analog input data, see Section 4.



Test analog out menu (1.4.2.5.3.2)

These values can be read and written. The status of various input data is displayed. Every item of output data can be set to manual mode and a value can be set for the output. The various items of output data are pre-configured in the program. To see the various items of analog output data, see Section 4.




Fan

0%	speed 0
25%	speed 1
50%	speed 2
100%	speed 3

GETINGE


Test digital in menu (1.4.2.5.3.3)

These values are read-only. The status of various input data is displayed. The various items of output data are pre-configured in the program. To see the various digital input data, see Section 4.



Test digital out menu (1.4.2.5.3.4)


These values can be read and written. The status of various output data is displayed. Every item of output data can be set to manual mode and switched on and off. The various items of output data are pre-configured in the program. To see the various digital output data, see Section 4.



GETINGE


Test user flag menu (1.4.2.5.3.5)

These values are read-only. The status of each flag is displayed. The various flags are preconfigured in the program.



Test printer (1.4.2.5.3.7)


During the printer test, the printer prints characters on the paper.



GETINGE


Test LED/buzzer display (1.4.2.5.3.8)

During the test, all LEDs light up and the buzzer sounds.




Save RAM in flash menu (1.4.2.6)

The RAM memory has battery backup, but during a cold start PACS loads data from the flash memory to the RAM memory and all changes made since the last time data was saved are lost.



Appliance info (1.4.3)

This menu shows the versions of the various program parts in PACS.



GETINGE

A-parameters

Using the operator code, the following parameters (A-parameters) can be changed.

PH2100 WASHING 1

Parameters	Setting range
Washing temperature	40 - 92 °C
Washing time	0 - 900 s
Dosing amount	0 - 500 ml
Dosing temperature	20 - 85 °C

PH2101 WASHING 2

Parameters	Setting range
Washing temperature	40 - 92 °C
Washing time	0 - 900 s
Dosing amount	0 - 500 ml
Dosing temperature	20 - 85 °C

PH2020 NEUTRALIZING

Parameters	Setting range
Washing temperature	40 - 92 °C
Washing time	0 - 900 s
Dosing amount	0 - 500 ml
Dosing temperature	20 - 85 °C

PH2000 CHEMICAL DISINF

Parameters	Setting range
Chemical disinfection temperature	30 - 60 °C
Chemical disinfection time	0 - 900 s
Dosing amount	0 - 500 ml
Dosing temperature	20 - 85 °C

PH3010 FINAL RINSE

Parameters	Setting range
Final rinse temperature	40 - 92 °C
Final rinse time	0 - 900 s
Dosing amount	0 - 500 ml
Dosing temperature	20 - 85 °C

PH4000 DRYING

Parameters	Setting range
Drying time	0 - 3600 s
Max chamber temperature	60 - 90 °C

GETINGE

P-parameters

Using any code down to the supervisor code, the following parameters (P-parameters) can be changed.

PH0000 STANDBY

Parameters	Setting range
Password	0 - 1
Booster standby	5 min - 1 hour
Chamber lighting	5 min - 1 hour

PH0001 START

Parameters	Setting range
Emptying time	0 - 60 s

PH1000 PRE-RINSE 1

Parameters	Setting range
Pre-rinsing time	0 - 600 s
Water type	CW, HW or CW + HW

PH1001 PRE-RINSE 2

Parameters	Setting range
Pre-rinsing time	0 - 600 s
Water type	CW, HW or CW + HW

PH1002 PRE-RINSE 3

Parameters	Setting range
Pre-rinsing time	0 - 600 s
Water type	CW, HW, CW + HW or none

PH2100 WASHING 1

Parameters	Setting range
Water type	CW, HW, CW + HW, DW or none
Dosing pump	1, 2, 3, 4

PH2101 WASHING 2

Parameters	Setting range
Water type	CW, HW, CW + HW, DW or none
Dosing pump	1, 2, 3, 4

PH2020 NEUTRALIZING

Parameters	Setting range
Water type	CW, HW, CW + HW, DW or none
Dosing pump	1, 2, 3, 4

PH2000 CHEMICAL DISINF

Parameters	Setting range
Water type	CW, HW, CW + HW, DW or none
Dosing pump	1, 2, 3, 4

PH3000 RINSE 1

Parameters	Setting range
Water type	CW, HW, CW + HW, DW or none
Rinse time	0 - 600 s

PH3001 RINSE 2

Parameters	Setting range
Water type	CW, HW, CW + HW, DW or none
Rinse time	0 - 600 s

PH3002 RINSE 3

Parameters	Setting range
Water type	CW, HW, CW + HW, DW or none
Rinse time	0 - 600 s

PH3010 FINAL RINSE

Parameters	Setting range
Conductivity	0 - 25
Conductivity measurement	0 - 1
Dosing pump	1, 2, 3, 4
Disinfection	0 - 1
Final rinse	0 - 1

PH4000 DRYING

Parameters	Setting range
Drying temperature	80 - 120 °C
Drying phase	0 - 1
Cooling time	0 - 1 h
Cooling temperature	60 - 95 °C

PH5000 Shutdown

GETINGE

PREVENTIVE MAINTENANCE

General

The required maintenance interval will depend largely on the quality of the incoming water, how often the machine is used and the nature of the goods to be sterilized. The maintenance interval will have to be determined in each individual case. We recommend that the stated maintenance operations are done at least at the specified intervals but once a year as a minimum. We also recommend that a function check is done once or twice a year.

Periodic maintenance



This may only be done by authorized personnel.



The machine is connected to the electricity supply and some components are live.

After installation, hose clips on the drain pump, circulation pump and booster pump must be retightened.

Check the drain valve and process valve for leaks once a month.

Component	Interval					
	Check yearly	Replace if necessary	Replace yearly	Replace every other year	Replace after 1000 hours	Re-placement time
Door seal	•	•				1 hour
Hoses between dosing pump and detergent container	•			•		1 hour
Hose between dosing pump and machine	•			•		1 hour
Filter in incoming media	•	•				1 hour
Overheat protection	•	•				1 hour
Hose in hose pump	•	•		•		1 hour
Washer arm bearings	•	•				1 hour
Spray arm journals	•	•				
Sterile filter in dryer	•	•	•			2 hours
Hoses to dryer	•	•				2 hours
Check valve in dryer	•	•				1 hour
Fan to dryer	•	•				3 hours
Ink ribbon for printer	•	•				10 min
Crush protection on door closing	•	•				1 hour
Process valve diaphragm	•	•				
Diaphragm in drain valve	•	•				
Cleaning of waste tank	•					
Cooling fans and filters in electrical cabinets	•	•				
Steam hoses (replace every five years)	•					
Check hose couplings for leaks	•					
Check process valve for leaks	•					
Check drain valve for leaks	•					
Make sure that the power cables are firmly attached in their sockets.	•					

Function check



This may only be done by authorized personnel.



The machine is connected to the electricity supply and some components are live.

Instruction manual, cable, switch

- Check that a goods placing sign has been put up on the wall behind the disinfectant.
- Check that the isolator switch on the wall is working and that the connecting cable is undamaged and free from defects.



Filters and valves

- Check that level switches and manual shutoff/opening valves are working properly.
- Check the filters in the supply line (see under Cleaning the filters in the supply line). Clean if necessary.
- Check all pipe couplings. Tighten and seal if necessary.
- Check filters in the ventilation grilles on the front of the electrical cabinet. See under Replacing filters in ventilation grilles. Replace if necessary.

Strainer

- Check that the coarse strainer and the fine strainer are correctly fitted and that they have been cleaned.

Controls

- The machine is operated with the buttons on the control panel.
- Check that the control buttons are working. If the buttons are working, a beep will be heard.
- While a program is running check that the yellow lamp at  is lit. When the program is complete, the green lamp at  should light up.

Insert for goods

- Check that the inserts for the machine dock properly with the water outlets.
- Check that spray arms (if fitted) rotate and are not clogged.
- Check that the goods to be cleaned are retained in the insert.
- Check the cleaning instructions of the goods manufacturer.
- To achieve the intended level of performance and safety, distribute the load evenly over the washing surface.
- Check the cleaning result visually when the process is complete.
- Check the accessories of the machine visually with regard to their intended use and function. For example, blocked ducts, worn and missing parts that might affect the performance of the machine. Water must be able to flow freely through the ducts in hollow instruments.

GETINGE

Door

Check the door safety function. Check that the door seal closes tight and is undamaged and that there is no leakage while a program is running. Clean or replace the seal if necessary.

Detergent dosing

Check that the suction hose and pump are full of detergent or rinse-aid before running a program. Check the amount of detergent with a measuring beaker.

Washing system



All supply line valves must be closed when working on the pipe system.

- Make sure that the spray arms can spin freely.
- Check that the holes in the spray arms are not blocked. Clean if necessary.
- Check that the coarse strainer in the bottom of the washing chamber is correctly installed. Clean if necessary.
- Check that all couplings connecting the washing system to the pump and chamber are leak tight. Tighten and seal if necessary.
- Check that the end plugs of the spray arm are correctly fitted.

Temperature check

- Check the temperature during a program run. Compare time and temperature with the program sheet. Time and temperature are especially important in the disinfection phase.
- The measuring equipment must be capable of continuously recording temperature and time. High-performance equipment is essential for reliable measuring results, because of the relatively rapid temperature changes.
- Only one measuring point in the centre of the machine is needed for the function check.

Note!

Washer-disinfectors that have been shown not to meet the requirements in terms of temperature, sequence, washing system and safety must not be used until the faults have been corrected.

Dryer

- Check seals and hoses for leaks once a year.
- Replace the sterile filter if necessary or in the event of an alarm.
- Check the operation of the check valve.

Hoses

- Check valve
- Heat exchanger
- Door
- Booster tank and booster pump
- Waste cooling
- Tighten hose clips

Printer

- Check ink ribbon cartridge
- Check the printout quality.


Cooling fans in electrical cabinets

- Check that the fans rotate and that the filters are not clogged.

Power cables

- Make sure that the power cables are firmly attached in their sockets.

Fault indications



Handling alarms

Handling alarms appear on the display in plain text.



The machine cannot be started until the fault has been put right.

The following messages can be displayed:


-
- Dose 1 low level** Empty container alarm 1, if detergent 1 is finished, a handling code is generated. The alarm is reset automatically when detergent is added.
 - Dose 2 low level** Empty container alarm 2, if detergent 2 is finished, a handling code is generated. The alarm is reset automatically when detergent is added.
 - Dose 3 low level** Empty container alarm 3, if detergent 3 is finished, a handling code is generated. The alarm is reset automatically when detergent is added.
 - Dose 4 low level** Empty container alarm 4, if detergent 4 is finished, a handling code is generated. The alarm is reset automatically when detergent is added.
-


Note!

The last process had access to detergent. A message is displayed for future processes.

GETINGE




Alarm

If the red lamp at  lights up, the process has been aborted because of a fault. The display shows a fault code.



Acknowledging a fault code

Acknowledge the fault code by:

- Noting the fault code
1. Cancel the acoustic signal by pressing . The machine remains locked but the program has been stopped.
 2. Correct the fault or call service personnel.
 3. Press  again. The display shows the password entry menu.
 4. Enter the password (558387) using the arrow keys and press . All liquid is drained from the machine and the soiled-side door is unlocked*.
 5. Remove the items or restart as usual.



The items in the machine have not undergone a complete process and must be washed again from the beginning with a new program.

If the items are still hot, handle them with care to avoid burns.

- * If the drain pump is faulty, water cannot be drained from the machine and the fault must be put right. The soiled-side door is unlocked as soon as the password is confirmed. This is so that the items can be removed and processed in another machine while the faulty machine awaits servicing. Program 16 must be run before the machine can be started again.

Troubleshooting

The table below describes the fault codes that may be generated and a possible action for each fault code.



This may only be done by authorized personnel. The machine is connected to the electricity supply and some components are live.

Fault code	Fault	Comment
A00	Power failure	In the event of a power failure, the process stops. The fault code is generated when the power returns.
A02	Process tank slow to fill with water.	The water level sensor (-B23, -B24, -B25) is not activated within two minutes of filling starting. Possible action: a. Check that the shutoff valves are open and that water is reaching the machine. b. Check that the solenoid valves open and that their filters are not clogged. c. Check that the booster pump works. d. Check level sensor
A03	Booster tank slow to fill with water.	The water level sensor (-B21) is not activated within two minutes of filling starting. Possible action: a. Check that the shutoff valves are open and that water is reaching the machine. b. Check that the solenoid valve opens and that its filter is not clogged.
A04	The washing chamber takes more than 20 seconds to empty	The water level sensor (-B10) is still activated after emptying of the machine has been running for 20 seconds. Possible action: a. Check that the drain valve (-M17) opens. b. Check that the strainer in the machine is not blocked. c. Check that the waste pump (-M02) pumps out water. d. Check level sensor
A05	Water leakage in the dryer.	Leakage detectors (-B12 and -B35) are not activated while the washing cycle is running. Possible action: a. Check that the check valves to the dryer connection are not damaged and are closing correctly (tight). b. Check level sensor
A06	Faulty locking, soiled side	The door locking switch (-S02) is not activated within 10 seconds of the start of locking, or the door locking switch (-02) failed during a program run. Possible action: a. Check that nothing is trapped in the door. b. Check that the door locking switch (-S02) is activated within 10 seconds on door locking. c. Check that the door locking motor (-M11) starts and that the sealing switch (-S52) is not activated. d. Check the setting of the frame

GETINGE

Fault code	Fault	Comment
A07	Faulty unlocking, soiled side	<p>The door locking switch (-S01) is not activated within 10 seconds of the start of locking.</p> <p>Possible action:</p> <ol style="list-style-type: none"> Check that nothing is trapped in the door. Check that the door locking switch (-S02) is activated within 10 seconds on door locking. Check that the door locking motor (-M11) starts and that the sealing switch (-S52) is not activated. Check the setting of the frame
A08	Faulty closing, soiled side	<p>The door locking switch (-S03) is not activated within 20 seconds of the start of locking or the closed door switch (S-03) failed during a program run. This fault code is also displayed if the door crush protection has been tripped.</p> <p>Possible action:</p> <ol style="list-style-type: none"> Check that nothing is trapped in the door. Check that the door closed switch (S-03) is activated within 20 seconds on door closing. Check that the door closing motor (-M10) starts and that the sealing switch (-S53) is not activated. Check the door motor chain and wire. Check the setting of the frame
A09	Faulty opening, soiled side	<p>The door opening switch (-S04) is not activated within 20 seconds of the start of opening.</p> <p>Possible action:</p> <ol style="list-style-type: none"> Check that nothing is trapped in the door. Check that the door open switch (-S04) is activated within 20 seconds on door opening. Check that the door opening motor (-M10) starts and that the sealing switch (-S54) is not activated. Check the door motor chain and wire. Check the setting of the frame
A10	Faulty locking, clean side	<p>The door locking switch (-S07) is not activated within 10 seconds of the start of locking, or the door locking switch (-S07) failed during a program run.</p> <p>Possible action:</p> <ol style="list-style-type: none"> Check that nothing is trapped in the door. Check that the door locking switch (-S07) is activated within 10 seconds on door locking. Check that the door locking motor (-M13) starts and that the sealing switch (-S56) is not activated. Check the setting of the frame
A11	Faulty unlocking, clean side	<p>The door locking switch (-S06) is not activated within 10 seconds of the start of locking.</p> <p>Possible action:</p> <ol style="list-style-type: none"> Check that nothing is trapped in the door. Check that the door locking switch (-S06) is activated within 10 seconds on door unlocking. Check that the door locking motor (-M13) starts and that the sealing switch (-S55) is activated. Check the setting of the frame

Fault code	Fault	Comment
A12	Faulty closing, clean side	<p>The door locking switch (-S08) is not activated within 20 seconds of the start of locking or the closed door switch (-S08) failed during a program run. This fault code is also displayed if the door crush protection has been tripped.</p> <p>Possible action:</p> <ol style="list-style-type: none"> Check that nothing is trapped in the door. Check that the door closed switch (S-08) is activated within 20 seconds on door closing. Check that the door closing motor (-M12) starts and that the sealing switch (-S57) is not activated. Check the door motor chain and wire. Check the setting of the frame
A13	Faulty opening, clean side	<p>The door opening switch (-S09) is not activated within 20 seconds of the start of opening.</p> <p>Possible action:</p> <ol style="list-style-type: none"> Check that nothing is trapped in the door. Check that the door open switch (-S09) is activated within 20 seconds on door opening. Check that the door opening motor (-M12) starts and that the sealing switch (-S58) is not activated. Check the setting of the frame
A14	Low flow, dosing 1	<p>Flowmeter (-B17) registers flow less than 10ml/20s from dosing pump (-M03).</p> <p>Possible action:</p> <ol style="list-style-type: none"> Check operation of the dosing pump. Check that there is detergent in the container. Check whether an empty container alarm has occurred. Check that there is no air in the flowmeter and that it is working. Check that the hoses are not blocked. Check the calibration of the flowmeter.
A15	Low flow, dosing 2	<p>Flowmeter (-B18) registers flow less than 10ml/20s from dosing pump (-M04).</p> <p>Possible action:</p> <ol style="list-style-type: none"> Check operation of the dosing pump. Check that there is detergent in the container. Check whether an empty container alarm has occurred. Check that there is no air in the flowmeter and that it is working. Check that the hoses are not blocked. Check the calibration of the flowmeter.
A16	Low flow, dosing 3.	<p>Flowmeter (-B19) registers flow less than 10ml/20s from dosing pump (-M05).</p> <p>Possible action:</p> <ol style="list-style-type: none"> Check operation of the dosing pump. Check that there is detergent in the container. Check whether an empty container alarm has occurred. Check that there is no air in the flowmeter and that it is working Check that the hoses are not blocked. Check the calibration of the flowmeter.

GETINGE

Fault code	Fault	Comment
A17	Low flow, dosing 4.	<p>Flowmeter (-B20) registers flow less than 10ml/20s from dosing pump (-M06).</p> <p>Possible action:</p> <ol style="list-style-type: none"> Check operation of the dosing pump. Check that there is detergent in the container. Check whether an empty container alarm has occurred. Check that there is no air in the flowmeter and that it is working. Check that the hoses are not blocked. Check the calibration of the flowmeter.
A18	High conductivity.	<p>The conductivity (-U01) is higher than the set value after the third repeat rinse.</p> <p>Possible action:</p> <ol style="list-style-type: none"> Check that the correct type of water is connected. Check for detergent leaks. Check that the process tank is clean. Check for deposits on the voltage measurement sensor. Check the emptying
A19	Low pressure in drying unit.	<p>The differential pressure (-B03) is 150 Pa.</p> <p>Possible action:</p> <ol style="list-style-type: none"> Check whether the fan, differential pressure meter, hoses or filter(s) are faulty. When changing a filter, check that the new filter is correctly installed.
A20	High pressure in drying unit.	<p>The differential pressure (-B03) is > 750 Pa .</p> <p>Possible action:</p> <ol style="list-style-type: none"> Check whether the filter is clogged. Check the check valve.
A21	Low pressure from the circulation pump.	<p>The pressure (-B02) is <20 kPa.</p> <p>Possible action:</p> <ol style="list-style-type: none"> Check the docking between machine and wash rack. Check that the pump impeller rotates easily. Check the direction of rotation (see installation instructions). Check that the detergent is not foaming. Check the amount of detergent dosed.
A22	High pressure from circulation pump.	<p>The pressure (-B02) is >200 kPa.</p> <p>Possible action:</p> <ol style="list-style-type: none"> Check that no nozzles in the washing arms are blocked.
A23	Low temperature in drying unit.	<p>The temperature (-B04) has not risen to 80 degrees C below the set value after five minutes.</p> <p>Possible action:</p> <ol style="list-style-type: none"> Check that there is power on all phases up to the element. Check that the airways to the filter are clear.
A24	Faulty temperature sensor in booster tank.	<p>The temperature (-B07) is <0°C or >130°C.</p> <p>Possible action:</p> <ol style="list-style-type: none"> Check the temperature sensor (for open-circuit or short-circuit)
A25	Faulty temperature sensor (controlling) in wash chamber.	<p>The temperature (-B05) is <0°C or >130°C.</p> <p>Possible action:</p> <ol style="list-style-type: none"> Check the temperature sensor (for open-circuit or short-circuit)

Fault code	Fault	Comment
A26	Faulty temperature sensor (independent) in wash chamber.	Independent. The temperature (-B06) is <math><0^{\circ}\text{C}</math> or $>130^{\circ}\text{C}$. Possible action: a. Check the temperature sensor (for open-circuit or short-circuit)
A27	Faulty temperature sensor in drying unit	The temperature (-B04) is <math><0^{\circ}\text{C}</math> or $>130^{\circ}\text{C}$. Possible action: a. Check the temperature sensor (for open-circuit or short-circuit)
A28	Faulty temp sensor in wash chamber. (Too low because of a heating fault.)	Wash temperature (-B05) has not risen by at least 10 degrees C after eight minutes' washing. Possible action for electrically heated machine: a. Check that there is power on all phases up to the elements. b. Check the voltage before and after the overheat cutout. If the overheat cutout has tripped it must be replaced. The overheat cutouts are not resettable. c. Check the calibration of the temperature sensor Possible action for a steam-heated machine: a. Check the steam valve. b. Check that the ball valve is open and that the incoming steam filter is clean. c. Check steam pressure (see installation instructions). d. Check condensate drain. e. Check that there is no back-pressure in the condensate drain. f. Check the calibration of the temperature sensor.
A29	Diff. temp in wash chamber	Wash temperatures (-B05 and -B06), dependent and independent, differ by more than ± 3 degrees C for three seconds. Possible action: a. Check the calibration of the temperature sensor (see the section Repair and adjustment and under Calibration) b. Check the temperature sensor.
A30	Faulty temp sensor in wash chamber. (Temperature too high because of a heating fault.)	The temperature in the wash chamber exceeds the maximum set temperature by more than five degrees C. Possible action for an electrically-heated machine: a. Check that the heating contactor is not stuck. b. Check that the heating elements are not short-circuited. c. Check the calibration of the temperature sensor (-B05) . Possible action for steam heated machine: a. Check that the steam valve for the chamber heater is not stuck. b. Check the calibration of the temperature sensor (-B05).
A31	High temperature in drying unit.	The temperature in the drying unit is above 130°C . Possible action: a. Check that the heating contactor is not stuck. b. Check that the heating elements are not short-circuited. c. Check the calibration of the temperature sensor (-B04).
A32	High temperature in booster tank.	The temperature in the booster tank is above 98°C . Possible action for an electrically-heated machine: a. Check that the heating contactor is not stuck. b. Check that the heating elements are not short-circuited. c. Check the calibration of the temperature sensor (-B07). Possible action for steam heated machine: a. Check that the steam valve for the booster tank is not stuck. b. Check the calibration of the temperature sensor (-B07).

GETINGE

Fault code	Fault	Comment
A33	Low disinfection temperature.	<p>The temperature in the wash chamber is below the set value for disinfection.</p> <p>Possible action for electrically heated machine:</p> <ol style="list-style-type: none"> Check that the heating contactor is not stuck. Check that the heating elements are not short-circuited. Check the calibration of the temperature sensor (-B05). <p>Possible action for a steam-heated machine:</p> <ol style="list-style-type: none"> Check that the chamber heating steam valve is not stuck. Check the calibration of the temperature sensor (-B05).
A34	Draining tank slow to empty.	<p>The water level sensor (-B26) is still activated within 3 minutes of the start of emptying.</p> <p>Possible action:</p> <ol style="list-style-type: none"> Check that the waste pump starts. Check that the waste tank outlet is not blocked. Check that the water level sensor (-B26) is working.
A35	Process valve position indication incorrect.	<p>Limit switches (-S20 or -S21) are not activated within 10 seconds of the process valve starting to open or close.</p> <p>Possible action:</p> <ol style="list-style-type: none"> Check that the process valve (-M16) starts. Check that the limit switch (-S20) indicates closed when the valve is trying to close. Check that the limit switch (-S21) indicates open when the valve is trying to open
A36	Wash chamber drain valve position indication incorrect drain valve.	<p>Limit switches (-S22 or -S23) are not activated within 10 seconds of the process valve starting to open or close.</p> <p>Possible action:</p> <ol style="list-style-type: none"> Check that the process valve (-M17) starts. Check that the limit switch (-S22) indicates closed when the valve is trying to close. Check that the limit switch (-S23) indicates open when the valve is trying to open
A37	Wash chamber slow to fill.	<p>The water level sensor is not activated within 25 seconds of the start of post-filling .</p> <p>Possible action:</p> <ol style="list-style-type: none"> Check that the process valve (-M16) opens. Check that the drain valve is closed and that it seals tight. Check that the sampling tap is closed.
A38	Faulty temp sensor in booster tank. (Temperature too low because of a heating fault.)	<p>The water temperature (-B07) in the booster tank has not risen to the set value within 10 minutes of the start of heating.</p> <p>Possible action for electrically heated machine:</p> <ol style="list-style-type: none"> Check that there is power on all phases up to the element. Check the voltage before and after the overheat cutout. If the overheat cutout has tripped it must be replaced. The overheat cutout is not resettable. <p>Possible action for steam heated machine:</p> <ol style="list-style-type: none"> Check the steam valve. Check that the ball valve is open and that the incoming steam filter is clean. Check steam pressure (see installation instructions). Check condensate drain. Check that there is no back-pressure in the condensate drain. Check the calibration of the temperature sensor (-B07).

Fault code	Fault	Comment
A39	External stop signal.	External connection not intact. Possible action: a. Check the connections at the terminal strip (-X06:9 and -X06:10) in the electrical cabinet.
A41	Faulty circulation pressure sensor.	The circulation pressure sensor (-B02) is <0kPa or >160kPa. Possible action: a. Check the circulation pressure sensor (for open or short circuit)
A42	Faulty pressure differential sensor in drying unit.	The differential pressure sensor (-B03) is <0Pa or >750Pa. Possible action: a. Check the differential pressure sensor (for open or short circuit)
A45	Monitoring system: Disinfection time + 60 sec.	The disinfection stage exceeds the set time by more than 60 seconds. Possible action for electrically heated machine: a. Check that there is power on all phases up to the elements. b. Check the voltage before and after the overheat cutouts. If the overheat cutout has tripped it must be replaced. The overheat cutout is not resettable. c. Check the calibration of the temperature sensor (-B07). d. Check the set temperature control parameters. Possible action for steam heated machine: a. Check the steam valve. b. Check that the ball valve is open and that the incoming steam filter is clean. c. Check steam pressure (see installation instructions). d. Check condensate drain. e. Check that there is no back-pressure in the condensate drain. f. Check the calibration of the temperature sensor (-B07). g. Check the set temperature control parameters
A46	Monitoring system: Diff. between temp. sensors in wash chamber.	See A29. Sensors for supervisor are called -B08 and -B09.
A47	Monitoring system: Circulation pressure low.	See A21
A48	Monitoring system: High conductivity.	See A18
A49	Monitoring system: Dosing flow low.	Flowmeters (-B17, -B18, -B19 or -B20) register less than 10ml/20s flow from dosing pump (-M03, -M04, -M05 or -M06). Possible action: a. Check operation of the dosing pump. b. Check that there is detergent in the container. c. Check whether an empty container alarm has occurred. d. Check that there is no air in the flowmeter and that it is working. e. Check that the hoses are not blocked. f. Check the calibration of the flowmeter.

GETINGE


Repair and adjustment

Connecting a PC

An RS-232 cable (art. no. 5010191-00) is needed to connect a PC to the washer-disinfector.

Proceed as follows:

1. Connect a cable between the PC and COM-port as shown below.
 - Connect the PC to X24 (if system software load connect PC to X25).
 - X25 is used mainly for T-doc (RS485) and printer (RS232 or RS485).
 - Connect the scanner to X32.



Connections

Fixed scanner


To connect the barcode scanner, proceed as follows.

1. Connect the scanner as shown in the circuit diagram below.

Power supply	Brown	+5V
	Blue	-5V
	Black	X304A2
	White	X304A3


2. Set type of communication. The communication settings are done in the service program; see menu tree, Sections 1.4.2.3.5.1 and 1.4.2.3.5.2.

Set COM2 (X24) scanner 2 Baud 9600.



3. Set the dipswitches in the machine to permit communication with the scanner.

The settings for dipswitches are made in the service program, see Menu tree chapter 1.4.2.4



J184

GETINGE


Printers

Custom FH190SP-24S3-0005

Proceed as follows to connect the printer to machine.

1. Connect the communication cable between the printer and connector X302/ Port X32.
2. Connect the power supply cable between the printer and connector X303.
3. Set type of communication. The communication settings are done in the service program; see menu tree, Sections 1.4.2.3.5.1 and 1.4.2.3.5.2.


Set Com port 1 = Printer. Baud rate 9600



J177

4. Set the print mode (only possible from CS100/1000).

Printer type = 24 CHAR, Printer mode = 1 (Only mode 1 is possible to this printer)



J178


Printer configuration

Check the printer configuration as follows.

- Cut off the power to the printer.
- Hold down the **FEED** and **PRINT** buttons at the same time and switch on the power to the printer.
- The printer is now in programming mode.
 - Press the **FEED** button to step through the parameter list (this is printed on the paper) and to confirm a changed parameter setting or that the set parameter is OK. Available parameter settings are listed in the table below.
 - Press the **PRINT** button to change between available settings for the current parameter. Press FEED when the desired setting is printed out.
- When the last parameter in the list has been confirmed, the printer automatically prints the entire new configuration. The printer is then ready for use.

Parameters	Available setting
Print mode	Custom emulation
	ESC/POS emulation
	iDP-emulation
	Print = Normal
	Print = Reverse
	Little
	Double width
	Double height
	Expanded
	Font 1
	Font 2
	CR-LF Honor CR
	CR-LF Ignore CR
Serial mode	Baud rate 300
	Baud rate 600
	Baud rate 1200
	Baud rate 2400
	Baud rate 4800
	Baud rate 9600
	Baud rate 19200
	Baud rate 38400
	Protocol = 8,N,1
	Protocol = 8,E,1
	Protocol = 8,0,1
	Protocol = 8,N,1
	Protocol = 7,N,2
	Protocol = 7,E,1
	Protocol = 7,0,1
	Flow control CTS-RTS
	Flow control XON-XOFF
Print key null	
Print key transmit \$OD	
Buffer 1K byte	
Buffer 24K byte	
Real time clock	Enable set RTCK
	Disable set RTCK
	Enable seconds
	Disable seconds
	Enable print time by key
Dis. print time by key	

Available settings



```

* END PROGRAMMING *
CUSTOM EMULATION
PRINT = REVERSE
LITTLE
FONT 1
CR-LF IGNORE CR
DISABLE SET RTCK
DISABLE SECONDS
DIS. PRINT TIME BY
KEY
BUFFER 1K BYTE
BAUD RATE = 9600
PROTOCOL = 8,N,1
FLOW CONTROL CTS-RTS
PRINT KEY NULL
    
```

Printout of current configuration


GETINGE

Lexmark C524

Proceed as follows to connect the printer to machine.

1. Connect the communication cable between the printer and connector X302/ Port X32.
2. Set type of communication. The communication settings are done in the service program; see menu tree, Sections 1.4.2.3.5.1 and 1.4.2.3.5.2.

Set Com port 1 = Printer. Baud rate 9600




J179


3. Set the print mode (only possible from CS100/1000).

Printer type = HP COLOR, Printer mode = 1-4 (1 = Only text, 2 = Only Graphics,

3 = Text + Graphics on the same page and 4 = Text and graphics but on separate pages)



J180




J175

J174


NetCom

Proceed as follows to connect the NetCom card.

1. Follow the installation instructions in the manual supplied with the NetCom card.
2. Set com port 3 = Comli, Mode= RS485, Baud 57600
3. Set the dipswitches in the machine to permit communication with the T-DOC (DS30-PC DISK LOG). The settings for dipswitches are made in the service program, see Menu tree chapter 1.4.2.4



J187



NetCom card

GETINGE


Connection AGS

AGS (Air Gliding System) is a transport system that automatically manages loading and unloading of the washer disinfector. Communication between the transport system's PLC and the washer disinfector takes place via the AS-i bus.

Proceed as follows to connect the machine.

1. Connect the AS-i node (see the spare part list for the part no.) to terminal block –X11 in the electrical cabinet.

Terminal block	Voltage	Current	Description
-X11:1	24VDC	<200mA	AS-i out 0
-X11:2	24VDC	<200mA	AS-i out 1
-X11:3	24VDC	<200mA	Voltage supply
-X11:4	24VDC	<200mA	AS-i I+
-X11:5	24VDC	<200mA	AS-i I1
-X11:6	24VDC	<200mA	AS-i I2
-X11:7	24VDC	<200mA	AS-i I3
-X11:8	24VDC	<200mA	Standby



AS-i Node


See the wiring diagram for additional description of the connection points.

2. Connect the communication cable to terminal block –X07. See the wiring diagram for additional description of the connection points.

Terminal block	Voltage	Current	Description
-X11:9-12	Only for internal communication	-	Communication between the washer disinfector and AGS
-X07:15-18	Only for internal communication	-	Communication between the washer disinfector and AGS

See the wiring diagram for additional description of the connection points.

3. Set the dipswitches in the machine to permit communication with the AGS. The settings for dipswitches are made in the service program, see Menu tree chapter 1.4.2.4



J181

4. Set the address on the washer disinfector's AS-i node. See the instruction in the manual supplied with AGS.

Connection loader/unloader

Loader/unloader is a system that automatically manages loading and unloading of the washer disinfecter. The loader/unloaders can be one or two positions. Communication between the loaders' PLC and the washer disinfecter takes place via a digital signal transfer.

Proceed as follows to prepared the machine for the loaders.

1. Connect the cables for the loader in the machine between terminal block –X07 in the electrical cabinet and connector –X261.

Terminal block	Voltage	Current	Description
-X07:1	24VDC	<500mA	Voltage supply to the loader
-X07:2			
-X07:3			
-X07:7	24VDC	<200mA	Ready signal from the loader
-X07:8			
-X07:11	24VDC	<200mA	Start signal to the loader
-X07:12			

See the wiring diagram for additional description of the connection points.

2. Connect the cables for the unloader in the machine between terminal block –X07 in the electrical cabinet and connector –X262.


Terminal block	Voltage	Current	Description
-X07:4	24VDC	<500mA	Voltage supply to the unloader
-X07:5			
-X07:6			
-X07:9	24VDC	<200mA	Ready signal from the unloader
-X07:10			
-X07:11	24VDC	<200mA	Start signal to the unloader
-X07:13			

See the wiring diagram for additional description of the connection points

3. Connect the compressed air hoses between incoming compressed air connection and each connection point on the loader/unloader.

GETINGE

4. Set the dipswitches in the machine to permit communication with each loader/unloader. The settings for dipswitches are made in the service program, see Menu tree chapter 1.4.2.4



5. Follow the instruction supplied with the loader/unloaders to connect the loader with the machine.

Termination central dosing

The machine is prepared for connection to an external dosing system. Communication between the washer disinfecter and the central dosing system takes place via a digital signal transfer.

The following signals are available for communication.

Terminal block	Voltage	Current	Description
-X04:1-2	Potential free	Max 1A	Start signal dosing 1
-X04:3-4	Potential free	Max 1A	Start signal dosing 2
-X04:5-6	Potential free	Max 1A	Start signal dosing 3
-X04:7-8	Potential free	Max 1A	Start signal dosing 4
-X04:9	24VDC	<200mA	Common +24VDC (*)
-X04:10	24VDC	<200mA	Detergent dosing 1 available (*). (Signal from the central dosing system that the detergent is available)
-X04:11	24VDC	<200mA	Detergent dosing 2 available (*). (Signal from the central dosing system that the detergent is available)
-X04:12	24VDC	<200mA	Detergent dosing 3 available (*). (Signal from the central dosing system that the detergent is available)
-X04:13	24VDC	<200mA	Detergent dosing 4 available (*). (Signal from the central dosing system that the detergent is available)
-X06:9-10	24VDC	<200mA	Ext. Stop signal (*). E.g. incorrect dosing.

(*) The cable length must not exceed 10 m. The potential free contact must be used if necessary.

GETINGE

Potential free contacts

The machine is prepared to supply specific information to an external system. There are a number of potential free contacts on the machine for this purpose.

The following signals are available on the machine.

Terminal block	Voltage	Current	Description
-X06:1-2	Potential free	Max 1A	Process running
-X06:3-4	Potential free	Max 1A	Process complete
-X06:5-6	Potential free	Max 1A	Alarms
-X06:7-8	Potential free	Max 1A	Forced ventilation
-X06:9-10	Potential free	<200mA	Ext. Stop signal (*). E.g. incorrect dosing.

(*) The cable length must not exceed 10 m. The potential free contact must be used if necessary.

Loading programs to flash memory

The flash memory (existing or new card) can be reloaded with new wash programs or a new system program. Loading new wash programs requires the CS-100/CS1000 program and loading of a new language version requires CS Tools. Both can be purchased via Getinge Academy. Instructions are supplied with CS-1000. System programs are loaded with Flashloader.

Loading system programs

Note:

Always make a backup copy before starting work on updating system programs.

1. Connect a PC to the machine; see under Connecting a PC.
2. Check that the machine is in STANDBY mode.
3. Make a backup copy by starting CS 1000 and choosing:
Tools/PACS RAM/Upload To File...

4. Save the *.prm file in your chosen location.




Figure 1

5. If using existing card, do a Save RAM In Flash (the set calibration values will then be automatically moved back after loading of the program(s))





Figure 2

6. Switch off the power to the machine with the main switch.

GETINGE

7. Move jumper 1 on the board for the PACS 350 control system from Normal to System Load. Check that jumper 2 is in the Flash position and that jumper 3 is in the ON position.



8. Switch on the power to the machine with the main switch. The display lights up but without text.
9. Start Flashloader from PC.

10. Set up as shown.




Figure 6

- Filename Choose the right program file (*.a37).
- Com Port The port to which you connected the data cable to your PC.
- Baud Rate Choose 38400
- All Sectors and Verbose must be checked (=selected).

11. Start loading by pressing Program !. The following image appears.




Figure 7

12. When loading is complete, the following image appears. Press OK.





Figure 8

GETINGE

13. Check that the battery jumper (3) is set to ON.
14. Switch off the power to the machine with the main switch.
15. Change the jumper (1) to Cold.
16. Switch on the power to the machine with the main switch. The display should now show:



17. Without switching off the power, move jumper 1 to the Normal position.
18. Close Flashloader.
19. Start CS-1000 and load wash programs; see instructions for CS-1000.

Load language files

Instructions for loading language files come with the CS-1000 package.

Note:

Always make a backup copy before starting work on updating system programs.

Loading a new application into PACS

With CS1000

1. Make a backup of the existing software. “Tools” “PACS RAM” “Upload to file (if this has not already been done).




Figure 1

2. Download the new software. “Tools” “PACS RAM” “Download From File”.




Figure 3





Figure 4

3. Start the machine and check that everything is as it should be.

GETINGE

- Switch off the power to the machine and install the “Flash prom” (if it is missing).



- Switch on the power. Flash the new software to “Flash prom”. “Tools” “PACS RAM” “Save RAM In Flash”. This may take a few seconds.





Figure 2

Reloading the backup from “flash prom” to PACS

Without CS1000

- Switch off the power to the machine and remove the old prom with a prom extractor.
 - Move jumper 1 to cold start. Power on the machine and wait for a beep.
- Now the display shows:
- Switch off the power to the machine. Install the new “flash prom”.



- Switch on the power. Now the new software has been loaded from the “flash prom” to the processor.
- Without switching off the power, move jumper 1 to the Normal position. Start the machine and make sure that everything is working as it should.

Cold start


Do a cold start when the machine has hung and you cannot proceed with the program.

1. Switch off the power to the machine.
2. Move the programming jumper (1) from Normal to Cold.
3. Switch on the power.
4. Move the programming jumper (1) from Coldstart to Normal. **NOTE:** The power is still on.
5. Set the doors to the home position using the service program (tab 5 of the Software description and settings, section headed Test digital output display (1.4.2.5.3.4) or CS1000.

Home position for the doors:

Soiled side = door unlocked and open

Clean side = door closed and locked



GETINGE

Changing user language

The language can be changed in two ways, via the control panel or via CS1000.

With user panel

The user language can be changed in the “Settings” “System menu” “Configuration” “Language Date format” menu. See menu tree in this manual.

With CS1000

The user panel language can be changed in the “System” “System configuration” menu.





Figure 5

Calibration

Calibrating PACS conductivity

To calibrate the conductivity meter, proceed as follows.


1. Connect a PC with the CS 1000 program installed to the disinfectant.
2. Press **[E]** on the conductivity meter.
3. Enter code 22 with **[+]** and **[-]**.
4. Press **[E]**. Setup 1 appears.
5. Choose Output med **[+]** and **[-]**.
6. Press **[E]**. Sel. Type appears.
7. Choose SIM med **[+]** and **[-]**.
8. Press **[E]**.
9. Choose 0 ... with **[+]** and **[-]** 22 mA.
10. Set 4 mA.
11. Start CS 1000 and choose Settings/Calibration/Analog Input Automatic...



V1563


GETINGE

12. Click Conductivity (A) and then Calibrate (B).




V1564

13. Enter the value 0 (C) and click Set Low.




V1565

14. Set 20 mA on the conductivity meter with \oplus and \ominus .
 15. Enter 500 (D) in CS 1000 and click Set High.



V1566

16. Check that the value (E) rises to 500.
17. Cancel the acoustic signal by pressing Close (F).




18. Press **[+]** and **[-]** at the same time. Output appears on the display.
19. Press **[E]**. Sel. Type appears.
20. Choose Lin. with **[-]**.
21. Press **[E]**.
22. Press **[+]** and **[-]** at the same time twice to log out of the conductivity meter.

GETINGE


Pressure sensor for circulation pump

To calibrate the pressure sensor for the circulation pump, proceed as follows.


1. Connect a PC with the CS 1000 program installed to the disinfectant.
2. Connect a process simulator to A01-X1;
+ on 3B
- on 3A
3. Set the process simulator to 4 mA.
4. Start CS 1000 and choose Settings/Calibration/Analog Input Automatic...



5. Click Pump pressure (A) and then Calibrate (B).




6. Enter the value 0 (C) and click Set Low.



V1568

7. Set the process simulator to 20 mA.
8. Enter 160 (D) in CS 1000 and click Set High.



V1569


9. Check that the value (E) rises to 160.
10. Log off CS 1000.

GETINGE

Temperature sensors - with resistor


Proceed as follows to calibrate the temperature sensors with the aid of resistors:

1. Connect a PC with the CS 1000 program installed to the disinfectant.
2. Insert resistors for 20 °C at the following places:
 - A01-X1 Chamber temperature 9A, 10A
 - A01-X2 Independent chamber temperature 5A, 6A
 - A01-X2 Booster tank 3A, 4A
 - A01-X5 Dryer 1A, 2A
3. Start CS 1000 and choose Settings/Calibration/Analog Input Automatic...



V1563

4. Click Temp booster, Temp chamber and Temp chamb indep (A), then click Calibrate (B).



V1570

5. Enter the value 20 (C) and click Set Low.

Calibration

Analog Input Manual | Analog Input Automatic | Bridge Compensation Table

Select	No	Symbolic Name	Type	Unit
<input type="checkbox"/>	AI00	CONDUCTIVITY	GENERAL	uS
<input type="checkbox"/>	AI01	PUMP PRESSURE	GENERAL	kPa
<input type="checkbox"/>	AI02	DRYER PRESSURE	GENERAL	Pa
<input type="checkbox"/>	AI03		GENERAL	
<input type="checkbox"/>	AI04	TEMP DRYER	GENERAL	C
<input checked="" type="checkbox"/>	AI05	TEMP BOOSTER	GENERAL	C
<input checked="" type="checkbox"/>	AI06	TEMP CHAMBER	GENERAL	C
<input checked="" type="checkbox"/>	AI07	TEMP CHAMB INDEP	GENERAL	C

No	Symbolic Name	Value	Unit	A-Gain	B-Offset
AI05	TEMP BOOSTER	19.3	C	1.000	0.0
AI06	TEMP CHAMBER	20.0	C	1.001	0.1
AI07	TEMP CHAMB INDEP	20.1	C	1.012	0.3

Reference

20 Set Low

0 Set High

Protocol Pacs protocol

V1571

6. Check that the value (D) rises to 20.
7. Replace resistors for 20 °C with resistors for 90 °C.
8. Enter 90 (E) in CS 1000 and click Set High.

Calibration

Analog Input Manual | Analog Input Automatic | Bridge Compensation Table

Select	No	Symbolic Name	Type	Unit
<input type="checkbox"/>	AI00	CONDUCTIVITY	GENERAL	uS
<input type="checkbox"/>	AI01	PUMP PRESSURE	GENERAL	kPa
<input type="checkbox"/>	AI02	DRYER PRESSURE	GENERAL	Pa
<input type="checkbox"/>	AI03		GENERAL	
<input type="checkbox"/>	AI04	TEMP DRYER	GENERAL	C
<input checked="" type="checkbox"/>	AI05	TEMP BOOSTER	GENERAL	C
<input checked="" type="checkbox"/>	AI06	TEMP CHAMBER	GENERAL	C
<input checked="" type="checkbox"/>	AI07	TEMP CHAMB INDEP	GENERAL	C

No	Symbolic Name	Value	Unit	A-Gain	B-Offset
AI05	TEMP BOOSTER	88.8	C	1.000	0.0
AI06	TEMP CHAMBER	89.7	C	1.001	0.1
AI07	TEMP CHAMB INDEP	90.1	C	1.012	0.3

Reference

20 Set Low

90 Set High

Protocol Pacs protocol

V1572


9. Check that the value (F) rises to 90.
10. Log off CS 1000.
11. Remove the resistors and reinstate the temperature sensors.

GETINGE

Temperature sensor - with ice bath and oil bath


Proceed as follows to calibrate the temperature sensors with the aid of an ice bath and an oil bath:

1. Connect a PC with the CS 1000 program installed to the disinfecter.
2. Prepare an ice bath and an oil bath.
The ice bath must consist of crushed ice in a bowl of cold water. The bath must stand for at least 20 minutes so that the temperature can stabilize.
The oil bath must be switched on for at least 45 minutes at the set temperature (100 °C) to stabilize the temperature.
3. Remove the temperature sensors from the disinfecter. Tape the sensors together.
4. Lower the temperature sensors into the ice bath together with an external thermometer.
5. Start CS 1000 and choose Settings/Calibration/Analog Input Automatic...



V1563

6. Click Temp booster, Temp chamber and Temp chamb indep (A), then click Calibrate (B).



V1571

7. Check that the reading of the external thermometer stabilizes. Enter the reading of the external thermometer (C) and click Set Low.

Calibration

Analog Input Manual | Analog Input Automatic | Bridge Compensation Table

Select	No	Symbolic Name	Type	Unit
<input type="checkbox"/>	AI00	CONDUCTIVITY	GENERAL	uS
<input type="checkbox"/>	AI01	PUMP PRESSURE	GENERAL	kPa
<input type="checkbox"/>	AI02	DRYER PRESSURE	GENERAL	Pa
<input type="checkbox"/>	AI03		GENERAL	
<input type="checkbox"/>	AI04	TEMP DRYER	GENERAL	C
<input checked="" type="checkbox"/>	AI05	TEMP BOOSTER	GENERAL	C
<input checked="" type="checkbox"/>	AI06	TEMP CHAMBER	GENERAL	C
<input checked="" type="checkbox"/>	AI07	TEMP CHAMB INDEP	GENERAL	C

No	Symbolic Name	Value	Unit	A-Gain	B-Offset
AI05	TEMP BOOSTER	19.3	C	1.000	0.0
AI06	TEMP CHAMBER	20.0	C	1.001	0.1
AI07	TEMP CHAMB INDEP	20.1	C	1.012	0.3

Reference

20 Set Low

0 Set High

Protocol Pags protocol

V1571

8. Check that the value (D) rises to the set value.
9. Move the temperature sensors and the external thermometer to the oil bath. Check that the reading of the external thermometer stabilizes. Enter the reading of the external thermometer (E) and click Set High.

Calibration

Analog Input Manual | Analog Input Automatic | Bridge Compensation Table

Select	No	Symbolic Name	Type	Unit
<input type="checkbox"/>	AI00	CONDUCTIVITY	GENERAL	uS
<input type="checkbox"/>	AI01	PUMP PRESSURE	GENERAL	kPa
<input type="checkbox"/>	AI02	DRYER PRESSURE	GENERAL	Pa
<input type="checkbox"/>	AI03		GENERAL	
<input type="checkbox"/>	AI04	TEMP DRYER	GENERAL	C
<input checked="" type="checkbox"/>	AI05	TEMP BOOSTER	GENERAL	C
<input checked="" type="checkbox"/>	AI06	TEMP CHAMBER	GENERAL	C
<input checked="" type="checkbox"/>	AI07	TEMP CHAMB INDEP	GENERAL	C

No	Symbolic Name	Value	Unit	A-Gain	B-Offset
AI05	TEMP BOOSTER	88.8	C	1.000	0.0
AI06	TEMP CHAMBER	89.7	C	1.001	0.1
AI07	TEMP CHAMB INDEP	90.1	C	1.012	0.3

Reference

20 Set Low

90 Set High

Protocol Pags protocol

V1572


10. Check that the value (F) rises to the set value.
11. Log off CS 1000.
12. Re-instate the temperature sensors.

GETINGE

Differential pressure gauge for dryer


To calibrate the differential pressure gauge for the dryer, proceed as follows.

1. Connect a PC with the CS 1000 program installed to the disinfectant.
2. Close the machine doors.
3. Connect an external differential pressure gauge in parallel with the existing gauge on the machine. Zero the external differential pressure gauge.
4. Start CS 1000 and choose Settings/Calibration/Analog Input Automatic...




V1563

5. Click Dryer pressure (A) and then Calibrate (B).



V1573

6. Enter the value 0 (C) and click Set Low.



V1574

7. Start the machine fan manually as follows:

>SETUP

Scroll to SETUP with . Press .

>SYSTEM
APPLIANCE INFO

Scroll to SYSTEM with . Press .

>ENTER PASSWORD

Enter password. Press .

>SERVICE
SAVE RAM IN FLASH

Scroll to SERVICE with . Press .

SERVICE MESSAGE
>DIAGNOSTICS

Scroll to DIAGNOSTICS with . Press .

>TEST ANALOG OUT
TEST DIGITAL IN

Scroll to TEST ANALOG OUT with . Press .

GETINGE

>01 FAN SPEED DRYER
AUT 100%

Scroll to 01 FAN SPEED DRYER with . Press .

>01 FAN SPEED DRYER
MAN 100%

Change AUT to MAN with . Set fan speed to 100 %.

8. Check the reading of the external differential pressure gauge. Enter the reading of gauge (D) in CS 1000 and click Set High.

The reading should be between 200 and 400 Pa.

If it is too high, the filter may be clogged; if it is too low, there may be a hole in the filter.

9. Check that the value (E) rises to the reading of the external differential pressure gauge.

V1574

10. Log off CS 1000.

11. Reinststate the fan.

>01 FAN SPEED DRYER
MAN 0%

Set fan speed to 0 %. **Change MAN to AUT with .**

Press .


12. Log out.

13. Reinststate the differential pressure gauge.


Calibration of drying sensor

To calibrate the drying sensor for the dryer, proceed as follows.

1. Connect a PC with the CS 1000 program installed to the disinfectant.
2. Connect a process simulator (0-5V) to A01-X1;
+ on 7A
- on 7B
3. Start CS 1000 and choose Settings/Calibration/Analog Input Automatic...




4. Click Humidity Sensor (A) and then Calibrate (B).



5. Set the process simulator to 0V.


GETINGE

6. Enter the value 0 (C) and click Set Low.



V1568

7. Set the process simulator to 5V.
8. Enter 100 (D) in CS 1000 and click Set High.



V1569


9. Check that the value (E) becomes 100%.
10. Log off CS 1000.

Dosing pumps and flow transmitters


Calibration of flow transmitters

Calibration of flow transmitters can only be done with CS1000.

Choose Settings – Calibration – Dose monitor automatic.




Choose the flow sensors you wish to calibrate by checking them in the boxes on the left (1). Then press Calibrate (2).




GETINGE

Information for the dose monitor(s) you chose is now displayed. Enter the amount of detergent to be dosed, for example 100 ml, in the “Desired volume” field (2). Place a measuring beaker under the detergent inlet in the machine as shown below.



Start calibration by pressing SET (3). The dosing pump starts and detergent is dispensed into the beaker.



When the pump stops, read off the amount of detergent in the beaker and enter it in the “Measured volume” field (4). Then press Calc. (5).

The calibration constant is now re-calculated and calibration is complete. If something goes wrong during calibration or if you want to cancel calibration for some reason, press the ABORT button (6).

Trim panels

Clean side and soiled side

To remove the trim panels, begin by removing the middle panel above and below the door on the side you want to remove. To remove the panel above the door, unscrew the screw in the lower edge of the panel. Then tilt the panel out and lift it down.


To remove the panel below the door, unscrew the screw in middle of the lower edge of the panel. Then push the panel up and lift it off.

To remove the panel above the detergent compartment, unscrew the screws from inside the detergent compartment, then push the panel sideways toward the door.

To remove the panels beside the door on the clean side release them at the top edge. Then lift them off.

Side panels

Start removing the middle panel by unscrewing the screws that retain it at the top edge. Then lift off the panel. Use the same method with the remaining panels.



GETINGE

Replacing a temperature sensor



This may only be done by authorized personnel. The machine is connected to the electricity supply and some components are live. Before starting work, make sure that the booster tank and the process tank are fully drained.



Hot surfaces and hot water

In wash chamber and dryer

- Remove the old temperature sensor by pulling it out of the seal.
- Push the new sensor in through the seal.




It is important that the sensor does not penetrate too far into the chamber, since it may be damaged in service.

After replacing a sensor in the chamber, check that the controlling and independent sensors show the same temperature. If not, calibrate as described under Calibration.

In a booster tank

- Remove the old temperature sensor by unscrewing the gland and pulling the sensor out.
- Push in the new sensor and tighten the gland.



Door

Position and operation, door switches



This may only be done by authorized personnel.


Before starting work, make sure that the machine is isolated from the electric power supply. Do not use magnetic material when adjusting the “Door locked” switch.

Before starting work, make sure that the booster tank and the process tank are fully drained.



Hot surfaces and hot water

The pictures show the door switches on the machine.



When the door is at its bottom position, the DOOR OPEN switch is activated and when the door is in the top position the DOOR CLOSED and DOOR UNLOCKED switches are activated.

When the motor has pulled the door into its inner position, the DOOR LOCKED switch is activated. If the door is obstructed on its way up and the force on the door is greater than 150 N, the DOOR UP safety switch stops the door. When the door is stopped, the motor drive unit turns around its fixing point and activates the safety switch. For adjustment, see under “Adjusting safety switches, DOOR UP”.

If the door is obstructed on its way down, the DOOR DOWN safety switch stops the door. The door is suspended on two wires. If the door is obstructed, the wires continue to be paid out, and a spring force activates the DOOR DOWN safety switch, stopping the door.


GETINGE

Adjusting door switches



This may only be done by authorized personnel. Before starting work, make sure that the machine is isolated from the electric power supply.

Check that the respective microswitches are activated. Adjust if necessary.



Adjusting DOOR UP safety switch




This may only be done by authorized personnel.




There are live parts in the machine. Take great care when working on it.

To prevent damage, the spring must be adjusted so that the door stops when a force of 150 N is applied to the door when the door is moving up. The illustration below shows how to adjust the spring.



J025



J013

GETINGE


Replacing the door seal



This may only be done by authorized personnel.

Before starting work, make sure that the machine is isolated from the electric power supply. Before starting work, make sure that the booster tank, process tank and the waste tank are fully drained.

- Remove door switches and bolts. (If a loading/unloading unit is installed, there are door switches on the left-hand side only). This is so that the door can be pushed down far enough to release the seal.
- Push the door down to its lower position.
- Pull off the old seal.
- Fit the new seal and press it firmly into place.
- Install door switches and bolts.




Removing the door



This may only be done by authorized personnel.
Before starting work, make sure that the machine is isolated from the electric power supply. Before starting work, make sure that the booster tank, process tank and the waste tank are fully drained.

- Remove the front panels.
- Remove door switches and the door switches of the loader/unloader (if there is one). Remove bolts.
- Remove leaf springs, bolts and spacers in the lower part of the frame.
- Remove the drain hose.
- Access the service program; Test the operation of the door.
- Move the door to the half-open position.
- Separate the door frame and the door closing mechanism.
- Free the door frame at the top edge. NOTE: Secure the frame so that it cannot fall forwards.
- Free the lower edge of the door frame. NOTE: Secure the frame so that it cannot fall down and suffer damage.
- The frame and door assembly can now be lifted out and placed on the floor or on a table.
- Release the wire from the door and pulley. There is only one wire secured between the pulleys and the door.



GETINGE

Adjusting the door closing force




This may only be done by authorized personnel.
Before starting work, make sure that the machine is isolated from the electric power supply. Before starting work, make sure that the booster tank, process tank and the waste tank are fully drained.

When door is in its top position, the motor pulls the door in from the outer to the inner position. The force with which it does this is adjusted with a spring as shown below.

Note:

The spring must never be fully compressed!



Adjusting the door frame

Hang the door horizontally when it has been attached to the pulleys on both sides. Secure the wire to the door frame with the screws at the top corners of the door.

Overheat protection



This may only be done by authorized personnel. Before starting work, make sure that the machine is isolated from the electric power supply. Before starting work, make sure that the booster tank, process tank and the waste tank are fully drained.



Hot surfaces

If the element overheats, the overheat cutout trips. If the overheat cutout has tripped it must be replaced. **The overheat cutouts are not resettable.**

Replacing the overheat protection in the booster tank


1. Dismantle the protective cover over the element.
 2. Pull the bulb out of the riser pipe.
 3. Dismantle the overheat cutout from its bracket.
 4. Install the new overheat cutout in the reverse order.
- Ensure that the bulb bottoms.

Replacing overheat protection in the main pipe

1. Dismantle the protective cover over the element.
 2. Pull the bulb out of the riser pipe.
 3. Dismantle the overheat cutout from its bracket.
 4. Install the new overheat cutout in the reverse order.
- Ensure that the bulb bottoms.

Note:

If the overheat cutout has tripped, both check valves to the dryer must be replaced. See replacing the check valve in the section Check valve to main pipe.



GETINGE


Cleaning the water and steam valve




This may only be done by authorized personnel.
Before starting work, make sure that the machine is isolated from the electric power supply. Before starting work, make sure that the booster tank, process tank and the waste tank are fully drained.

The filters in the solenoid valves should be regularly checked and cleaned if necessary.

Water valve



Steam valve



Dryer




This may only be done by authorized personnel.

Before starting work, make sure that the machine is isolated from the electric power supply. Before starting work, make sure that the booster tank, process tank and the waste tank are fully drained.

- Check seals and hoses for leaks once a year.
- Replace the sterile filter (1) if necessary or in the event of an alarm.
- Make sure that the filter seals tight when reinstalled, otherwise there is a risk of alarm.

Changing the filter

To change the filter, release the clips on either side of the dryer. Tilt back the cover and change the filter. If necessary, adjust the clips so that the cover seals tight.




Fan replacement and checking

Lift up the dryer cover and unscrew the screws on the ring that presses the fan down. Lift out the old fan and install the new one. Press the fan down with the ring and refit the screws.

Check valves to main pipe

Unscrew the screws that hold the two pipes together. Separate the pipes and replace the old check valve. It is important that the flap on the check valve is positioned at the top.




GETINGE

Conductivity measurement (extra equipment)

Conductivity is measured with equipment from Endress+Hauser. (If the machine is equipped with a monitoring system, the conductivity must be measured as described under Conductivity measurement in Chapter 9.)



This may only be done by authorized personnel.



Function in washing process

The conductivity meter monitors the quality of the water in the final rinse, independently of the process control. If the conductivity in the final rinse is higher than the preset value, the machine is emptied and the final rinse is repeated automatically.

If, after three repetitions, the conductivity is still above the preset value, the process is stopped and fault code 11 appears on the display.

Measuring range

The normal measuring range is 0-500 µ S/cm

Check the output signal from conductivity meter

To check the output signal, proceed as follows.

1. Press **[E]** on the conductivity meter.
2. Enter code 22 with **[+]** and **[-]**.
3. Press **[E]**. Setup 1 appears.
4. Choose Output med **[+]** and **[-]**.
5. Press **[E]**. Lin appears on the upper line and Sel. Type appears on the bottom line.
6. Press **[E]**.
7. Choose 4-20 mA with **[+]** and **[-]**.
8. Press **[E]**.
9. Set 0/4 mA = 0.000 µS/cm with **[+]** and **[-]**.
10. Press **[E]**.
11. Set 20 mA = 500 µS/cm with **[+]** and **[-]**.
12. Press **[E]**.
13. Press **[+]** and **[-]** at the same time to log out.


Setting the cell constant

To set the cell constant, proceed as follows:

1. Press **[E]**.
2. Enter code 22 with **[+]** and **[-]**.
3. Press **[E]**. Setup 1 appears.
4. Press **[E]** until the display shows Cellconst.
5. With **[+]** and **[-]**, set the relevant cell constant; see the calibration certificate. (Comes with the sensor).
6. Press **[E]** three times. The display shows Setup 1.
7. Press **[+]** and **[-]** at the same time to log out.

Replacing the main board


Always remove the flash prom when replacing the main board. After replacing the board, follow the instructions in this manual for cold starting with flash prom.



GETINGE

Replacing the expansion board

The expansion board is jumpered so that the processor can identify which card is which. Jumpers may have to be repositioned when a board is replaced. Jumping is done as shown in the illustration. Set the potentiometer to its maximum position.



V2029b

Replacing fuses

Electrically heated

Fuse			
Tag no.	Rang	Rated Current	Description
-F01		16 A	Heater #1 Chamber
-F02		16 A	Heater #2 Chamber
-F03		16 A	Heater Booster tank
-F04		13A	Heater Dryer unit
Fuse			
Tag no.	Type	Rated Current	Description
-F11	C	10A	Frequency Converter
-F12	C	20 A	Main supply
-F13	C	10A	Dryer Fan #1
-F14	C	10A	Dryer Fan #2
-F15	C	6A	Main supply Control voltage
-F16	C	4 A	Main supply PACS300
-F101	T	500mA	Conductivity transmitter
-F102	T	500mA	Digital outputs
-F103	T	500mA	Power Supply Infeeder
-F104	T	500mA	Power Supply Outfeeder
-F105	T	500mA	Hardware Interlocks
-F106	T	500mA	Printer
-F201	T	500mA	Auto Scanner
-F202	T	500mA	Hand scanner
-F203	T	2 A	T-doc card

GETINGE

Steam heated

Fuse			
Tag no.	Rang	Rated Current	Description
-F04		13A	Heater Dryer unit
Fuse			
Tag no.	Type	Rated Current	Description
-F11	C	10A	Frequency Converter
-F12	C	20 A	Main supply
-F13	C	10A	Dryer Fan #1
-F14	C	10A	Dryer Fan #2
-F15	C	6A	Main supply Control voltage
-F16	C	4 A	Main supply PACS300
-F101	T	500mA	Conductivity transmitter
-F102	T	500mA	Digital outputs
-F103	T	500mA	Power Supply Infeeder
-F104	T	500mA	Power Supply Outfeeder
-F105	T	500mA	Hardware Interlocks
-F106	T	500mA	Printer
-F201	T	500mA	Auto Scanner
-F202	T	500mA	Hand scanner
-F203	T	2 A	T-doc card

Replacing a hose to a hose pump




This may only be done by authorized personnel.

Before starting work, make sure that the machine is isolated from the electric power supply.

There are three grades of hose for installation in the pump, depending on the detergent used. For article numbers see the spare parts list.

- Remove the cover (3) by unscrewing screw A.
- Disconnect the hoses at connections B and C.
- Take out the entire unit including hose (2) (a complete spare parts kit).
- Install the new unit.
- Refit the cover.
- Always check the dosing amount after replacing a pump and/or a hose.



*References on electrical diagram

GETINGE

Setting detergent and rinse-aid quantities




This may only be done by authorized personnel.



The machine is connected to the electricity supply and some components are live.

- Dispense detergent or rinse-aid into a measuring beaker. Check that the suction hose and pump are full before the check.
- Push the suction hose down into the beaker and measure the consumption during an entire cleaning program. Lift up the hose when reading the volume. Adjust if necessary and repeat the measurement until the amount conforms to the manufacturer's recommendations (see Calibration of flow transmitters in this manual).
- If necessary, adjust the dosing time in the service program.



Servicing the booster tank



It is essential to drain the process tank and the booster tank when servicing the booster tank and its valves. This is in order to prevent scalding, since the temperature of the water in the booster tank is about 90°C.



Hot parts

Booster tank with drain tap

If machine has not been used for some time (48 hours) the booster tank must be drained and program number 16 run.


To drain the booster tank, dismantle the front trim panels on the soiled side. Drainage is then done via a drain valve located on the soiled side of the tank. Make sure that the tap is not open before unscrewing the plug. If a nipple with G ¼ male thread is used, together with the associated hose, the hose can be fitted to the drain tap. The tank can now be drained. The capacity of the tank is about 32 litres.

After draining, check that the drain tap is working properly. Seal the plug with PTFE tape and refit it.

The microswitch must be checked as well, since it activates the booster tank.

When servicing is complete, check the entire system for water leaks.

The booster tank must be refilled before a process is started. To do this, open the DW valve via the control system. This is important, in order to avoid unwanted fault codes when starting the machine.



Overheat protection

If the element overheats, the overheat cutout trips. If the overheat cutout has tripped it must be replaced. **The overheat cutouts are not resettable.**

GETINGE

Process valve and diaphragm



This may only be done by authorized personnel.

Before starting work, make sure that the machine is isolated from the electric power supply. Before starting work, make sure that the booster tank, process tank and the waste tank are fully drained.



Hot surfaces and hot water

Checking

Check for leaks and visible damage. Check that there is no dirt or deposit on the diaphragm.

Adjusting (adjustment allowances)


To adjust the process valve, turn the nut on the top of the diaphragm. The distance from the top edge of the plastic to the bottom edge of the bolt attachment must be 19 mm.

Repair

Remove the roof and lift up the process tank. Then release the motor fixing and unscrew the hose clips that retain the diaphragm. Lift out the old motor and install the new one. Re-assemble in the reverse order.

Replacing the diaphragm

Empty the tank (max 55 litres). Lift up the process tank and remove the pin that holds the arm in place. Loosen the hose clip between the tank and the diaphragm. Press out the diaphragm from inside the chamber. Replace the diaphragm at five-year intervals.



J052

Booster pump



This may only be done by authorized personnel.

Before starting work, make sure that the machine is isolated from the electric power supply.

Before starting work, make sure that the booster tank, process tank and the waste tank are fully drained.



The pump body may be electrically live.

Before starting work, make sure that the pump body is not live.




Hot surfaces

Separate connector -M14-X1. Unscrew the hose clips and disconnect the hoses from the pump.

Unscrew the fixing screws and remove the pump. Install the new pump, reconnect the hoses and tighten the hose clips. Check the hose connections.

Re-connect connector -M14-X1.



Booster pump

J004

GETINGE

Process tank



This may only be done by authorized personnel.

Before starting work, make sure that the machine is isolated from the electric power supply.

Before starting work, make sure that the booster tank, process tank and the waste tank are fully drained.



Hot surfaces and hot water

Draining the process tank

The process tank is drained via the drain valve above the electrical cabinet. Connect a hose to the valve and then drain the tank.

Replacing a sensor

Remove the sensor from the tank and fit a new one.

Cleaning


Disconnect the hose from the water inlet. Using a brush, clean the inside of the tank through the hole.

Disinfecting the process tank






To disinfect the process tank, run program 16.

Volume calibration

Dispense 40 litres of water into the tank. Adjust the level sensor until you get a signal for the middle level (-B24).





Hose routing for process tank with top connection




GETINGE


Hose routing for process tank with floor connection




Cold water and hot water



Cold water, hot water and distilled water



Cold water and hot water with drain cooling



Cold water, hot water and distilled water with drain cooling

Drain valve



This may only be done by authorized personnel.

Before starting work, make sure that the machine is isolated from the electric power supply.

Before starting work, make sure that the booster tank, process tank and the waste tank are fully drained.



Hot surfaces and hot water

Checking

Check for leaks and visible damage. Check that there is no dirt or deposit on the diaphragm.

Adjusting (adjustment allowances)



Slacken the nut, hold back the copper washer and turn the bolt. Adjust the valve so that it closes tight.

Repair

Unscrew the four screws securing the motor and slacken the hose clips that retain the diaphragm.


Replacing the diaphragm

To access the diaphragm, it is necessary to remove the booster pump and motor mounting bracket. Remove the diaphragm hose clip from the clean side. Replace the diaphragm in the drain valve at five-year intervals.



J073

Hose clips



J003

GETINGE

Waste tank



This may only be done by authorized personnel.

Before starting work, make sure that the machine is isolated from the electric power supply.

Before starting work, make sure that the booster tank, process tank and the waste tank are fully drained.




Hot surfaces and hot water

Replacing and adjusting sensors

To replace the sensor, release the metal plate around the sensor and lift out the sensor.

Manual cleaning

Release the plate where the sensor is mounted. Remove the plate with the sensor and clean with a brush.



Waste pump



This may only be done by authorized personnel.

Before starting work, make sure that the machine is isolated from the electric power supply.

Before starting work, make sure that the booster tank, process tank and the waste tank are fully drained.




Hot surfaces and hot water

Checking

Check that there are no leaks from the pump or hoses.

Replacement

Empty the waste tank manually. It contains up to 55 litres. Release the hose clips and remove the pump from its mounting. Install a new pump and reconnect the hoses. Tighten the hose clips and check that there are no leaks from the pump or hoses.



J049

Drain pump

GETINGE

Water valves



This may only be done by authorized personnel.

Before starting work, make sure that the machine is isolated from the electric power supply.

Before starting work, make sure that the booster tank, process tank and the waste tank are fully drained.


Before starting work, make sure that the water is turned off and disconnected.



Hot parts

Replacing a filter

Remove the water valve from its mounting and disconnect the hose. In the hose connection there is a filter. To remove it, pull it straight out.



Replacing the valve

Free the valve and its connections from its mounting and replace it.

Steam valves and condensation traps



This may only be done by authorized personnel.

Before starting work, make sure that the machine is isolated from the electric power supply. Before starting work, make sure that the booster tank, process tank and the waste tank are fully drained.


Make sure that the water and steam supplies are shut off and disconnected before work begins.



Hot parts

Replacing and cleaning filters

Unscrew the filter from its position. Pull out the filter and clean or replace it.




Replacing a steam hose

The steam hose must be replaced at five-yearly intervals. Unscrew the hose clips and disconnect the hose from the taper coupling. Install the new hose in the same position as the old one. Connect the hose to the couplings and tighten the hose clips. Check for leaks.

GETINGE

Detergent cabinet

The shelves in the detergent compartment can be moved by unhooking them and pulling them out. The middle shelf is fixed.



Dosing pump and flow transmitter



This may only be done by authorized personnel.

Before starting work, make sure that the machine is isolated from the electric power supply.

Before starting work, make sure that the booster tank, process tank and the waste tank are fully drained.


Take care, as there may still be corrosive agents in the dosing pumps.

Replacing a dosing pump

Unscrew the plate holding the dosing pumps and the flow transmitters. Feed out the hoses so that the plate can be taken out of the detergent compartment. Separate the dosing pump so that it can be taken off the plate. Install the new flowmeter in the reverse order. When the replacement flowmeter has been installed, check for leaks at the hoses.

Replacing a flow transmitter

Unscrew the plate holding the dosing pumps and the flow transmitters. Feed out the hoses so that the plate can be taken out of the detergent compartment. Remove the defective flow transmitter. Install the new flow transmitter in the reverse order. When the replacement flow transmitter has been installed, check for leaks at the hoses.



GETINGE

Replacing a pressure sensor




This may only be done by authorized personnel.

Before starting work, make sure that the machine is isolated from the electric power supply.

Before starting work, make sure that the booster tank, process tank and the waste tank are fully drained.

Unscrew the screws that secure the sensor and disconnect the wiring. Install the new sensor and re-connect the wiring as on the old sensor. After installation, check for leaks at the hoses.



Replacing the differential pressure sensor




This may only be done by authorized personnel.

Before starting work, make sure that the machine is isolated from the electric power supply.

Before starting work, make sure that the booster tank, process tank and the waste tank are fully drained.

Unscrew the screws that secure the sensor and disconnect the wiring. Install the new sensor and re-connect the wiring as on the old sensor. Check the calibration.



J022

GETINGE


Frequency converter

Replacement




This may only be done by authorized personnel.
Before starting work, make sure that the machine is isolated from the electric power supply.

Wait at least 15 minutes before starting work.



The frequency converter is located behind the electrical cabinet on the clean side of the machine.


- Remove the cover plate with the OP-panel on the clean side.
- Disconnect the supply cables to the frequency converter. The cables are connected to interference suppression filter Z04.
- Separate the control cable connector marked U04-X2.
- Disconnect the motor cable from the frequency converter and remove the clamp that secures the motor cable to the EMC plate of the frequency converter.
- Unscrew the fixing screws (four) and remove the frequency converter.
- Install the new frequency converter in the reverse order and configure it.
- Check the direction of rotation of the circulation pump. If it is wrong, switch off the power and change the phase sequence. **NOTE: This must be done on the motor cable.**



Configuration

The frequency converter is programmed via a cable with RJ45 connectors at both ends (a patch cable).

Connect the cable to the frequency converter as shown below. Connect the other end of the cable via an adapter to the COM port (RS232) of a PC.



The frequency converter is programmed via the PowerSuitePC software or via the frequency converter panel.

Before programming starts, the machine must be powered on for communication between PC and frequency converter to work.

Then set the values for the various parameters as listed in the table below. See the rows with a grey shaded background.

380-415VAC

Code	Label	Value	Default Value	Address
ACC	Acceleration ramp time	5.0 s	3.0 s	9001
ADC	Automatic DC injection	Yes: DC inj. for adj. time	Yes: DC inj. for adj. time	10401
ADCO	Drive CANopen address	0	0	6051
AI1A	Configuration of AI1	Configuration reference 1	Configuration reference 1	4821
AI2A	Configuration of AI2	Summing input 2	Summing input 2	4822
AI3A	Configuration of AI3	Not configured	Not configured	4823
AO1T	Configuration of AO1	Configuration 0-20 mA	Configuration 0-20 mA	4601
ATR	Automatic restart	No	No	7122
BDCO	CANopen trans. speed	125 kbit/s	125 kbit/s	6053
BFR	Std. motor frequency	50 Hz	50 Hz	3015
BLC	Brake control	Not assigned	Not assigned	10001
BRA	Decel ramp adaptation	Yes	Yes	9003
CHP	Switching, motor 2	Not assigned	Not assigned	8011

GETINGE

CLI	Internal current limit	4.9 A	8.2 A	9201
COL	Stop for CANopen flt.COF	Freewheel	Freewheel	7011
COS	Motor power factor	0.80	0.81	9606
CRH3	Value for high speed AI3	20.0 mA	20.0 mA	4444
CRL3	Value for low speed AI3	4.0 mA	4.0 mA	4434
CTD	Motor current detection	4.9 A	5.5 A	11001
DCI	DC brake via logic input	Not assigned	Not assigned	11203
DEC	Deceleration ramp time	5.0 s	3.0 s	9002
DO	AOC/AOV assignment	Not assigned	Not assigned	5031
DRN	Derating for undervoltage	No	No	7007
EPL	Stop mode at external flt.	Freewheel	Freewheel	7006
ERCO	Error registry CANopen	0	0	6056
ETF	External fault	Not assigned	Not assigned	7131
FLG	Frequency loop gain	20 %	20 %	9620
FLO	Forced local mode	Not assigned	Not assigned	8431
FLR	Catch on fly	No	No	3110
FR1	Configuration reference 1	Analog input AI1	Analog input AI1	8413
FR2	Configuration reference 2	Not configured	Not configured	8414
FRS	Nominal motor frequency	50.0 Hz	50.0 Hz	9602
FRT	Ramp 2 switch frequency	0.0 Hz	0.0 Hz	9011
FST	Fast stop	Not assigned	Not assigned	11204
FTD	Motor freq threshold	50.0 Hz	50.0 Hz	11003
HSP	High Speed	50.0 Hz	50.0 Hz	3104
INH	Fault inhibit	Not assigned	Not assigned	7125
IPL	Loss of input phase	Yes	Yes	7002
ITH	Motor thermal Current	4.9 A	5.5 A	9622
JF2	Skip frequency 2	0.0 Hz	0.0 Hz	11302
JOG	Jog operation	Not assigned	Not assigned	11110
JPF	Skip frequency	0.0 Hz	0.0 Hz	11301
LAC	Function access level	Access to std. functions	Access to std. functions	3006
LAF	Limit forward direction	Not assigned	Not assigned	11601
LAR	Limit reverse direction	Not assigned	Not assigned	11602
LC2	Eneble current limit 2	Not assigned	Not assigned	9202
LCC	Remote terminal control	No	No	64003
LFF	Fall back speed	10.0 Hz	10.0 Hz	7080
LFL	Stop mode at loss 4-20 mA	Fault ignored	Fault ignored	7003
LI1A	Config. logic input 1	Forward	Forward	4801
LI2A	Config. logic input 2	Reverse	Reverse	4802
LI3A	Config. logic input 3	Select 2 preset speeds	Select 2 preset speeds	4803
LI4A	Config. logic input 4	Select 4 preset speeds	Select 4 preset speeds	4804
LI5A	Config. logic input 5	Not configured	Not configured	4805
LI6A	Config. logic input 6	Not configured	Not configured	4806
LSP	Low Speed	0.0 Hz	0.0 Hz	3105
NCR	Nominal motor current	4.9 A	5.1 A	9603
NRD	Motor Noise Reduction	Yes	Yes	3107
NSP	Nominal motor speed	2840 rpm	1430 rpm	9604

NST	Freewheel stop	Not assigned	Not assigned	11202
OHL	Stop mode at drive oheat	Freewheel	Freewheel	7008
OLL	Stop mode at motor oheat	Freewheel	Freewheel	7009
OPL	Output Phase Loss	OPF fault	OPF fault	9611
PIF	PI regulator feedback	Not configured	Not configured	11901
PS16	Enable 16 preset speeds	Not assigned	Not assigned	11404
PS2	Enable 2 preset speeds	Logic input LI3	Logic input LI3	11401
PS4	Enable 4 preset speeds	Logic input LI4	Logic input LI4	11402
PS8	Enable 8 preset speeds	Not assigned	Not assigned	11403
PST	STOP Key Priority	Yes	Yes	64002
R1	Relay R1	Drive fault	Drive fault	5001
R2	Relay R2	Not assigned	Not assigned	5002
RFC	Enable switching refs.	Configuration reference 1	Configuration reference 1	8411
RPS	Ramp switching	Not assigned	Not assigned	9010
RPT	Type of ramp	Linear ramp	Linear ramp	9004
RRS	Reverse	Logic input LI2	Logic input LI2	11105
RSC	Cold stator resistance	Inactiv.	Inactiv.	9643
RSF	Fault reset	Not assigned	Not assigned	7124
SA2	Summing input 2	Analog input AI2	Analog input AI2	11801
SA3	Summing input 2	Not configured	Not configured	11802
SDC1	DC current at standstill	3.8 A	3.8 A	10403
SDC2	DC current at standstill 2	2.7 A	2.4 A	10405
SDS	Display scale factor	30.0	30.0	12001
SFR	Drive switching frequency	9.0 kHz	4.0 kHz	3102
SLL	Stop mode at Modbus SLF	Freewheel	Freewheel	7010
SLP	Slip Compensation	100 %	100 %	9625
SP2	Preset speed 2	40.0 Hz	10.0 Hz	11410
SP3	Preset speed 3	50.0 Hz	15.0 Hz	11411
SP4	Preset speed 4	40.0 Hz	20.0 Hz	11412
SRF	Disable speed loop filter	No	No	9101
STA	Frequency loop stability	20 %	20 %	9621
STP	Ctrlrd stop on power loss	Lock drive freewheel stop	Lock drive freewheel stop	7004
STT	Normal stop mode	On ramp	On ramp	11201
TCC	2 wire or 3 wire control	2-wire control	2-wire control	11101
TCT	Type of 2 wire control	Edge triggered	Edge triggered	11102
TDC1	DC injection time	0.5 s	0.5 s	10402
TDC2	2nd DC injection time	0.0 s	0.0 s	10404
TFR	Max output frequency	60.0 Hz	60.0 Hz	3103
TLS	Low speed time out	0.0 s	0.0 s	11701
TNL	Auto-tuning fault config	Yes	Yes	7012
TTD	Motor thermal threshold	100 %	100 %	11002
TUN	Automatic tuning	Not assigned	Not assigned	9608
UFR	Voltage boost	20 %	20 %	9623
UFT	Select type of U/F ratio	Sensorless flux vector ctrl	Sensorless flux vector ctrl	9607
UNS	Nominal motor voltage	400 V	400 V	9601

GETINGE

200-240VAC

Code	Label	Value	Defalut value	Address
ACC	Acceleration ramp time	5.0 s	3.0 s	9001
ADC	Automatic DC injection	Yes: DC inj. for adj. time	Yes: DC inj. for adj. time	10401
ADCO	Drive CANOpen address	0	0	4051
AI1A	Configuration of AI1	Configuration reference 1	Configuration reference 1	4821
AI2A	Configuration of AI2	Summing input 2	Summing input 2	4822
AI3A	Configuration of AI3	Not configured	Not configured	4823
AO1T	Configuration of AO1	Configuration 0-20 mA	Configuration 0-20 mA	4601
ATR	Automatic restart	No	No	7122
BDCO	CANOpen trans. speed	125 kbit/s	125 kbit/s	6053
BFR	Std. motor frequency	50 Hz	50 Hz	3015
BLC	Brake control	Not assigned	Not assigned	10001
BRA	Decel ramp adaptation	Yes	Yes	9003
CHP	Switching, motor 2	Not assigned	Not assigned	8011
CLI	Internal current limit	8.5 A	26.2 A	9201
COL	Stop for CANOpen flt.COF	Freewheel	Freewheel	7011
COS	Motor power factor	0.80	0.79	9606
CRH3	Value for high speed AI3	20.0 mA	20.0 mA	4444
CRL3	Value for low speed AI3	4.0 mA	4.0 mA	4434
CTD	Motor current detection	8.5 A	17.5 A	11001
DCI	DC brake via logic input	Not assigned	Not assigned	11203
DEC	Deceleration ramp time	5.0 s	3.0 s	9002
DO	AOC/AOV assignment	Not assigned	Not assigned	5031
DRN	Derating for undervoltage	No	No	7007
EPL	Stop mode at external flt.	Freewheel	Freewheel	7006
ERCO	Error registry CANOpen	0	0	6056
ETF	External fault	Not assigned	Not assigned	7131
FLG	Frequency loop gain	20 %	20 %	9620
FLO	Forced local mode	Not assigned	Not assigned	8431
FLR	Catch on fly	No	No	3110
FR1	Configuration reference 1	Analog input AI1	Analog input AI1	8413
FR2	Configuration reference 2	Not configured	Not configured	8414
FRS	Nominal motor frequency	50.0 Hz	50.0 Hz	9602
FRT	Ramp 2 switch frequency	0.0 Hz	0.0 Hz	9011
FST	Fast stop	Not assigned	Not assigned	11204
FTD	Motor freq threshold	50.0 Hz	50.0 Hz	11003
HSP	High Speed	50.0 Hz	50.0 Hz	3104
INH	Fault inhibit	Not assigned	Not assigned	7125
IPL	Loss of input phase	Yes	Yes	7002
ITH	Motor thermal Current	8.5 A	17.5 A	9622
JF2	Skip frequency 2	0.0 Hz	0.0 Hz	11302
JOG	Jog operation	Not assigned	Not assigned	11110
JPF	Skip frequency	0.0 Hz	0.0 Hz	11301
LAC	Function access level	Access to std. functions	Access to std. functions	3006

LAF	Limit forward direction	Not assigned	Not assigned	11601
LAR	Limit reverse direction	Not assigned	Not assigned	11602
LC2	Eneble current limit 2	Not assigned	Not assigned	9202
LCC	Remote terminal control	No	No	64003
LFF	Fall back speed	10.0 Hz	10.0 Hz	7080
LFL	Stop mode at loss 4-20 mA	Fault ignored	Fault ignored	7003
LI1A	Config. logic input 1	Forward	Forward	4801
LI2A	Config. logic input 2	Reverse	Reverse	4802
LI3A	Config. logic input 3	Select 2 preset speeds	Select 2 preset speeds	4803
LI4A	Config. logic input 4	Select 4 preset speeds	Select 4 preset speeds	4804
LI5A	Config. logic input 5	Not configured	Not configured	4805
LI6A	Config. logic input 6	Not configured	Not configured	4806
LSP	Low Speed	0.0 Hz	0.0 Hz	3105
NCR	Nominal motor current	8.5 A	15.8 A	9603
NRD	Motor Noise Reduction	Yes	Yes	3107
NSP	Nominal motor speed	2840 rpm	1425 rpm	9604
NST	Freewheel stop	Not assigned	Not assigned	11202
OHL	Stop mode at drive oheat	Freewheel	Freewheel	7008
OLL	Stop mode at motor oheat	Freewheel	Freewheel	7009
OPL	Output Phase Loss	OPF fault	OPF fault	9611
PIF	PI regulator feedback	Not configured	Not configured	11901
PS16	Enable 16 preset speeds	Not assigned	Not assigned	11404
PS2	Enable 2 preset speeds	Logic input LI3	Logic input LI3	11401
PS4	Enable 4 preset speeds	Logic input LI4	Logic input LI4	11402
PS8	Enable 8 preset speeds	Not assigned	Not assigned	11403
PST	STOP Key Priority	Yes	Yes	64002
R1	Relay R1	Drive fault	Drive fault	5001
R2	Relay R2	Not assigned	Not assigned	5002
RFC	Enable switching refs.	Configuration reference 1	Configuration reference 1	8411
RPS	Ramp switching	Not assigned	Not assigned	9010
RPT	Type of ramp	Linear ramp	Linear ramp	9004
RRS	Reverse	Logic input LI2	Logic input LI2	11105
RSC	Cold stator resistance	Inactiv.	Inactiv.	9643
RSF	Fault reset	Not assigned	Not assigned	7124
SA2	Summing input 2	Analog input AI2	Analog input AI2	11801
SA3	Summing input 2	Not configured	Not configured	11802
SDC1	DC current at standstill	3.8 A	3.8 A	10403
SDC2	DC current at standstill 2	8.7 A	4.2 A	10405
SDS	Display scale factor	30.0	30.0	12001
SFR	Drive switching frequency	9.0 kHz	4.0 kHz	3102
SLL	Stop mode at Modbus SLF	Freewheel	Freewheel	7010
SLP	Slip Compensation	100 %	100 %	9625
SP2	Preset speed 2	40.0 Hz	10.0 Hz	11410
SP3	Preset speed 3	50.0 Hz	15.0 Hz	11411
SP4	Preset speed 4	40.0 Hz	20.0 Hz	11412
SRF	Disable speed loop filter	No	No	9101

GETINGE


STA	Frequency loop stability	20 %	20 %	9621
STP	CtrlId stop on power loss	Lock drive freewheel stop	Lock drive freewheel stop	7004
STT	Normal stop mode	On ramp	On ramp	11201
TCC	2 wire or 3 wire control	2-wire control	2-wire control	11101
TCT	Type of 2 wire control	Edge triggered	Edge triggered	11102
TDC1	DC injection time	0.5 s	0.5 s	10402
TDC2	2nd DC injection time	0.0 s	0.0 s	10404
TFR	Max output frequency	60.0 Hz	60.0 Hz	3103
TLS	Low speed time out	0.0 s	0.0 s	11701
TNL	Auto-tuning fault config	Yes	Yes	7012
TTD	Motor thermal threshold	100 %	100 %	11002
TUN	Automatic tuning	Not assigned	Not assigned	9608
UFR	Voltage boost	20 %	20 %	9623
UFT	Select type of U/F ratio	Sensorless flux vector ctrl	Sensorless flux vector ctrl	9607
UNS	Nominal motor voltage	400 V	400 V	9601

MONITORING SYSTEM

Description

Getinge Monitoring System is an independent monitoring system that is used together with Getinge Disinfection AB' dishwasher. The Monitoring System has its own PACS 350 system and control panel. The purpose of the system is to monitor five parameters:

- the pressure in the circulation circuit when the pump is running.
- the temperature during the disinfection phase.
- the duration (length) of the disinfection phase.
- the conductivity in the disinfection phase.
- The flow in the dosing circuit during dosing.



V1975


GETINGE

Software description and settings

Control panel

The buttons on the control panel are used to navigate in the menu tree.

Display



The screen has two lines, each with a capacity of 20 characters.

Information or error messages appear on the bottom line and replace the text that would otherwise appear there.





P01 POWER CLEAN
SUPERVISOR

Menu selection buttons



There are five navigation buttons on the panel. These fixed buttons are four arrow buttons that control the cursor (◀, ▶, ⬇, and ⬆) and ↵.

- • ◀ Used to go back one step (up one level) in menus. If the button is held down for a little longer, you are returned to the main menu.
- • ▶ Not used in menus and lists.
- • ⬇ Shows the next object in the list.
- • ⬆ Shows the previous object in the list.
- • ↵ Goes to the chosen object in the list or opens a field for editing if there is an editable field.

Scrolling in menus and lists


You can use , ,  and  to scroll through menus and lists. You can scroll either line by line or two lines at a time, depending on what is displayed. The top line of the list may look like the example below.

```
>PRINT LAST PRG.
  SYSTEM          v
```

The angle bracket “>” to the left of the top line shows which object will be chosen if you press . Bottom right there is a “v” indicating that there are more objects in the list which are displayed if you press .







This is what you see if you are in a list. The “arrows” to the right show that there are objects both above and below the displayed line.

```
>SYSTEM          ^
  APPLIANCE INFO
```

When you reach the end of the object list, only one up-arrow appears at the right edge of the display. Menus and lists are “endless”; you can reach the top of the list by pressing  at the end of the list.

```
  SYSTEM          ^
>APPLIANCE INFO
```

Field editing

 opens the chosen field for editing. The content of the field is changed with  or . These arrow keys scroll in an endless list containing numbers. When a field is opened for editing, the first character is highlighted. To move the cursor use  or . Entered values are saved when you press . On saving, the system checks that the value is in the permitted range.






GETINGE

Passwords

There are two passwords with different levels of authorisation in the system program:

- Supervisor - contact service for code.
- Programming - contact service for code.

Note: In the menu tree, where a password must be entered, there is a letter code (between PW: A-K) which indicates which function the respective password level gives authorisation for.

When a password is being entered, the top line shows “ENTER PASSWORD”. Each digit can be changed with  and .  and  toggle between the digits. Press  to confirm the entered password.

If the wrong password is entered, “WRONG PASSWORD” appears on the first line. Press  to return to the display that shows “ENTER PASSWORD”

Note: The password cannot be changed.

Supervisor

Code in menu tree	Authority to change
A	Parameters:
B	Calender (time and date)
C	Sensor calibration
D	Acknowledge alarms
H	Process-critical configurations, Parameters of type P
J	Password configuration
K	Documentation

Programming

Code in menu tree	Authority to change
A	Parameters:
B	Calender (time and date)
C	Sensor calibration
D	Acknowledge alarms
E	Service message
F	DIP switches
G	Non-critical system configurations
H	Process-critical configurations, Parameters of type P
I	Programming (phases and programs)
J	Password configuration
K	Documentation

P-parameters

Using the authorisation code, the following parameters (P-parameters) can be changed.

Parameter	Type	Description	Range	Default
DISINF TEMP	P	Disinfection phase*	20-90 °C	90
DEV TEMP 1	P	Deviation temp sensor 1	0,0-3,0	1,0
DEV TEMP 2	P	Deviation temp sensor 2	0,0-3,0	1,0
CIRC PRESS H	P	Maximum pressure in circulation circuit	150,0-300,0	200,0
CIRC PRESS L	P	Minimum pressure in circulation circuit	0,0-50,0	20,0
COND FR H	P	Maximim conductivity at 90 °C	0,0-250,0	4,0
DISINF TIME	P	Disinfection time*	0-10	00:01:00


* Disinfection time and temperature must be the same as on the PACS system on the machine.


GETINGE

Connecting a PC

An RS-232 cable is needed to connect a PC to the washer disinfector.

Proceed as follows:

- 1. Connect a cable between the PC and port X25 as shown below.
- 2. Set type of communication. The communication settings are done in the service program; see Chapter Software description and settings. Proceed as follows:
 - Go into Communication setup COM 0 (1.4.2.3.5.1); see Chapter 4 Software description and settings.
 - Choose COMLI PROTOCOL and press . Exit the service program.



Loading programs to flash memory

The flash memory (existing or new card) can be reloaded with new wash programs or a new system program. Loading new wash programs requires the CS-100/CS1000 program and loading of a new language version requires CSTools. Both can be purchased via Getinge Academy. Instructions are supplied with CS-1000. System programs are loaded with Flashloader.

Loading system programs

Note:

Always make a backup copy before starting work on updating system programs.

1. Connect a PC to the machine; see under Connecting a PC.
2. Check that the machine is in STANDBY mode.
3. Make a backup copy by starting CS 1000 and choosing:
Tools/PACS RAM/Upload To File...

4. Save the *.prm file in your chosen location.




Figure 1

5. If using existing card, do a Save RAM In Flash (the set calibration values will then be automatically moved back after loading of the program(s))





Figure 2

6. Switch off the power to the machine with the main switch.

GETINGE

7. Move jumper 1 on the board for the PACS 350 control system from Normal to System Load. Check that jumper 2 is in the Flash position and that jumper 3 is in the ON position.



8. Switch on the power to the machine with the main switch. The display lights up but without text.
9. Start Flashloader from PC.

10. Set up as shown.




Figure 6

- Filename Choose the right program file (*.a37).
- Com Port The port to which you connected the data cable to your PC.
- Baud Rate Choose 38400
- All Sectors and Verbose must be checked (=selected).

11. Start loading by pressing Program !. The following image appears.




Figure 7

12. When loading is complete, the following image appears. Press OK.




Figure 8

GETINGE

13. Check that the battery jumper (3) is set to ON.
14. Switch off the power to the machine with the main switch.
15. Change the jumper (1) to Cold.
16. Switch on the power to the machine with the main switch. The display should now show:



17. Without switching off the power, move jumper 1 to the Normal position.
18. Close Flashloader.
19. Start CS-1000 and load wash programs; see instructions for CS-1000.

Cold start

Perform a cold start as described under “Cold start” .

Calibration of the Monitoring system

See calibration procedure for the machine

GETINGE

Australia

Getinge Australia Pty Ltd
PO Box 50, Bulimba QLD 4172
Unit 1, 205 Queensport Rd.
Murarrie QLD 4173
info@getinge.com.au
Phone: +61-7 3399 3311

Belgium

Getinge NV
Vosveld 4 B-2
B-2110 Wijnegem
info@getinge.be
Phone: +32-33 542 865

Canada

Getinge Canada Ltd
1575 South Gateway Road,
Unit C Mississauga
Ontario L4W 5J1
info@getingecastle.ca
Phone: +1-905 629 8777

China

Getinge (Suzhou) Co.Ltd
No.158,Fang Zhou Road, Suzhou
Industrial Park 15021 Suzhou,
Jiangsu Province P.R.China
info@getinge.com.cn
Phone: +86- 51 262 838 966

Getinge Shanghai Trading Co. Ltd.
Rm 1988 Tower B,
CityCentr, 100 Zunyi Rd.
200051 Shanghai P.R.
info@getinge.com.cn
Phone: +86- 21 623 72 408

Denmark

Getinge Danmark A/S
Firskovvej 23
DK-2800 Lyngby
getinge.danmark@getinge.com
Phone: +45-45 93 27 27

Finland

Getinge Finland AB
Ängsgatan 8
FI-02200 Esbo
getinge@getinge.fi
Phone: +35-89 6824 120

France

Getinge France SAS
BP 49, avenue du Canada
ZA de Courtaboeuf
Les Ulis, FR-91942
getinge.france@getinge.fr
Phone: +33-1 64 86 89 00

Germany

Getinge Vertrieb & Service GmbH
Kehler Strasse 31
764 37 RASTATT
TYSKLAND
Tel: +49-7222 932 306
Fax: +49-7222 932 597
e-mail: info.inco-de@getinge.com

Italy

Getinge S.p.A
via Poggio Verde, 34
00148 Roma
info@getinge.it
Phone: +39-06 656 631

Japan

Toshin Takanaawa Build. 9F, 3-11-3
Takanawa Minato-Ku
Tokyo
JP-108-0074
Phone: +81 3 5791 7560

Netherlands

Getinge B.V.
Fruiteniersstraat 27, Zwijndrecht
Postbus 1004
NL-3330 CA Zwijndrecht
info@getinge.nl
Phone: +31-78 610 24 33

Norway

Getinge Norge A/S
Ryenstubben 2
0679 Oslo
info@getinge.no
Phone: +47-23 051 180

Poland

Getinge Poland
Ul. Lirowa 27
02-387 Warszawa
office@getinge.pl
Phone: +48-22 882 06 26

Singapore

Getinge International Far East Pte. Ltd.
20 Bendemeer Road,
#06-02, Cyberhub Building
Singapore, SG-339914
Phone: + 65- 6396 7298

South Africa

Getinge South Africa (Pty) Ltd
P O Box 48492
Hercules
Pretoria SA 0002
getinge@mweb.co.za
Phone: +27-123 721 370

Spain

Getinge Iberica SL
P.E. San Fernando, Avda. Castilla 2,
Edif. Francia 1era planta
San Fernando de Henares
Madrid ES-28830
administracion@getinge.es
Phone: + 34-916 78 26 26

Sweden

Getinge International AB
P O Box 69
SE-310 44 Getinge
info@getinge.com
Phone: +46-35 15 55 00

Switzerland

Getinge ALFA AG
Weidenweg 17
4310 Rheinfelden
info@alfa.ag
www.getingealfa.ch
Phone: +41-61 836 15 15

United Kingdom

Getinge UK Ltd
Orchard Way
Calladine Park
Sutton-In-Ashfield
Notts NG 17 1JU
sales@getinge.co.uk
Phone: +44-1623510033

USA

Getinge USA Inc.
1777 East Henrietta Road
Rochester, NY 14623-3133
info@getingeusa.com
www.getingeusa.com
Phone: +1-5,854,751,400

GETINGE
www.getinge.com